

Operating Instructions of Robot

---SD Series Robot

ADTECH A为兴

Adtech (Shenzhen) Technology Co., Ltd.

Add: 5th Floor, Tianxia IC Industrial Park, Yiyuan Road, MaJialong, Nanshan District, Shenzhen City, Guangdong Province, P.R.China.

TEL: +86-755-26722719 FAX: 0755-26722718-816

Email: tech@adtechcn.com Web: http://www.adtechcn.com



Copyright

Adtech (Shenzhen) Technology Co., Ltd. (Adtech hereafter) is in possession of the copyright of this manual. Without the permission of Adtech, the imitation, copy, transcription and translation by any organization or individual are prohibited. This manual doesn't contain any assurance, stance or implication in any form. Adtech and the employees are not responsible for any direct or indirect data disclosure, profits loss or cause termination caused by this manual or any information about mentioned products in this manual. In addition, the products and data in this manual are subject to changes without prior notice.

All rights reserved.

Adtech (Shenzhen) CNC Technology Co., Ltd.



Contents

| Chapter 1 Installation and Maintenance of Robot | 1 - |
|--|--------|
| 1. Installation precautions | 1 - |
| 1.1 Warning and caution labels | |
| 1.2 Ensuring appropriate installation environment | 3 - |
| 1.3 Ensuring operating space | |
| 1.4 Installing the controller outside of the restricted space of the | robot |
| | 4 - |
| 1.5 Installing the instruments | 4 - |
| 1.6 Wiring and protection of air pipes | 4 - |
| 1.7 Ensuring D type grounding | 4 - |
| 1.8 Installing emergency switch | 4 - |
| 1.9 Installing running status indicator | 5 - |
| 1.10 Installing protection rail | 5 - |
| 1.11 Setting the motion space of robot | 5 - |
| 1.12 Prohibiting refitting the robot | 6 - |
| 1.13 Cleaning the tools | 6 - |
| 1.14 Ensuring the illumination | 6 - |
| 1.15 Preventing flying off of clamped objects | 6 - |
| 1.16 Pasting warning labels | 6 - |
| 2. Operating precautions | 7 - |
| 2.1 Developing and effectively implementing "Operating Rules" | 7 - |
| 2.2 Ensuring the safety of operators in restricted space | 8 - |
| 2.3 Spot inspection before guide and other operations | 8 - |
| 2.4 Release of residual pressure | 8 - |
| 2.5 Confirming the precautions during operating | 8 - |
| 2.6 Precautions during automatic running | 8 - |
| 2.7 Maintenance precautions | 9 - |
| 2.8 Daily spot inspection and periodic inspection | 9 - |
| 2.9 Safety regulations | 9 - |
| 3. SD series robot body | - 10 - |
| 3.1 Basic structure of the robot | - 10 - |
| 3.2 Performance parameter of the robot | - 15 - |
| 3.3 Electrical configuration of the robot body | - 16 - |
| 4. Controller of SD series robot | - 20 - |
| 4.1 Introduction of the controller structure | - 20 - |
| 4.2 Extended port of the controller | - 24 - |
| 4.3 Port of controller over-load connector | - 24 - |



| Demonstrator of SD series robot | 26 - |
|--|---------|
| 5.1 Illustration of front panel | 26 - |
| 5.2 Illustration of rear panel | 30 - |
| 6. Robot Installation | 31 - |
| 6.1 Ensuring appropriate installation environment | 31 - |
| 6.2 Installation method of the robot body | 33 - |
| 6.3 Installing method of robot controller | 33 - |
| 6.4 Connection between robot body and controller | 34 - |
| 6.5 Electrical wiring and air tubing methods of robot body | 34 - |
| 6.6 Installing method of work fixture | 34 - |
| 7. Robot maintenance | 35 - |
| 7.1 Category and Objective of Maintenance Spot Inspection | 35 - |
| 7.2 Operation matters of spot inspections | 35 - |
| Chapter 2 Basic Operation | 37 - |
| 1. Changes in specification of robot | 37 - |
| 1.1 Meaning of changing robot specifications | 37 - |
| 1.2 Software limit | 37 - |
| 2. Status Bar of the Teaching Box | 43 - |
| 2.1 Running mode | 43 - |
| 2.2 Enabling status | 44 - |
| 2.3 Program running status | 44 - |
| 2.4 Program running mode | 45 - |
| 2.5 Welding simulation | 45 - |
| 2.6 Emergency stop button status | 46 - |
| 2.7 Reference coordinate system | 46 - |
| 2.8 Tool | 47 - |
| 2.9 Velocity | 47 - |
| 2.10 Alarm information display | 48 - |
| 2.11 Alarm information confirmation button | 48 - |
| 3. Operation of the Function Interface | 49 - |
| 3.1 Setting interface | 49 - |
| 3.2 IO monitoring | 61 - |
| 3.3 Tool | 69 - |
| 3.4 Coordination system | 81 - |
| 3.5 Variable | 91 - |
| 3.6 Engineering | - 100 - |
| 3.7 Program | - 106 - |
| 3.8 Position | - 111 - |
| 3.9 Message | - 118 - |



| Chapter 3 Advanced Programming | 121 - |
|---|-------------|
| 1. Jog operation of robot | 121 - |
| 1.1 Continuous jog | 121 - |
| 1.2 Incremental jog | 121 - |
| 1.3 Jog of absolute position (not being enabled tempora | rily) 122 - |
| 2. Run program | 122 - |
| 2.1 Manual mode | 122 - |
| 2.2 Auto mode | 125 - |
| 3. Variable types and programming instructions | 125 - |
| 3.1 Introduction of variable types | 125 - |
| 3.2 Motion statement | 134 - |
| 3.3 System parameters | 155 - |
| 3.4 Stream statement | 164 - |
| 3.5 I/O instruction | 176 - |
| 3.6 Mathematical function instruction | 212 - |
| 3.7 Bit operation instruments | 225 - |
| 3.8 Operators | 234 - |
| Appendix: Error codes and processing methods | - 235 - |



Chapter 1 Installation and Maintenance of Robot

Please read these instructions (manual) carefully in order to operate the SD 500 robot safely and effectively, ensure the safety of operators and other staff, as well as to avoid the production accidents such as damage to other equipment. Maximum space: The maximum space that the terminal actuator, workpiece, additional devices and other robot parts can move; this range is only predicted in design. Restricted space: The motion space of the robot that restricted by the limiter and other mechanical devices. Motion space: The motion space restricted with the software. Operating space: The restricted operating space of the robot when the task program is operating the robot.

1. Installation precautions

This section is the safety precautions of operating the robot. Please follow the related laws and regulations and ask qualified personnel to install the robot and related devices.


1.1 Warning and caution labels

The warning labels are pasted on the robot and controller. Specific hazard exists near the position pasted with the warning label. Please follow the warning on the label. The relevant labels and meanings are shown in Table 1-1.


Warning and caution labels Meaning Arm Y support is required to prevent **A** CAUTION 注 意 Arm Y support is required to prevent manipulator from tipping over when removing base mounting 拆除底座螺栓时将Y臂支撑以防 robot from tipping over when removing 止机器人翻倒。 base mounting bolts. Improper installation or operation can **▲** WARNING Improper installation or operation can result in serious injury or death. Read owner's manual and all warning labels before operation. result in serious injury or death. Read 不正确的安装或操作会导致严重受 伤或死亡。 在操作前请阅读用户手册和所有警 owner's manual and all warning labels 告标签。 before operation.

Table 1-1 Warnings and Caution









1.2 Ensuring appropriate installation environment

The SD500 robot does not meet dust-proof, mist-proof or explosion-proof specifications, and thus cannot be installed in the following environment.

- (1) With inflammable gases or liquids;
- (2) Scattered with metal chips and other conductive substances;
- (3) With acid, alkaline and other corrosive gases;
- (4) With mists such as cutting liquid and milling liquid;
- (5) With mists such as sulfur cutting liquid and milling liquid;
- (6) Near large transformer, large output high frequency oscillator, large electromagnetic contact, electric welder and other electromagnetic interferences.

Attention: If oil is prohibited in the environment of certain industries such as electronics, food and medical, please discuss separately. The robot is lubricated but it isn't airtight, and thus oil may leak. Please select the sealing type according to the environment.



The ambient temperature when the robot operates should be within the range of 0~40 °C, and the humidity shall be below 90% with no condensation. In order to ensure the normal operation of the robot, avoid installing it under excessive vibration and shock.

1.3 Ensuring operating space

Please reserve sufficient space for safe teaching and spot inspection before installing the robot and peripheral equipment.

1.4 Installing the controller outside of the restricted space of the robot

The robot controller, multifunctional teaching pendant and miniature teaching pendant should be hung outside the restricted space of the robot, and must be installed in the place where the operating status of the robot can be checked.

1.5 Installing the instruments

The pressure gauge, oil pressure meter and other instruments must be installed in the place that the operators can check at any moment.

1.6 Wiring and protection of air pipes

To avoid damaging the electrical wires and hydraulic air pipes, please protect them with shield or equivalent.

1.7 Ensuring D type grounding

The power grounding of the robot is in D type (grounding resistance is lower than 100Ω).

1.8 Installing emergency switch

To make sure that the robot can be stopped immediately upon emergency, please install the emergency switch at the place easily accessible. Thereinto,

- (1) The emergency switch must be red.
- (2) When the emergency switch is pressed, the robot cannot be reset automatically even if other personnel operate improperly.
- (3) The emergency switch and the power switch should be installed separately.



1.9 Installing running status indicator

Please install the indicator at the place where the operators can check the status (pause, emergency or failure) of the robot.

1.10 Installing protection rail

Install the protection rail to keep the operators and other personnel out of the restricted space of the robot. Follow the precautions below to install the protection rail:

- (1) Make sure that the protection rail cannot be moved or removed easily.
- (2) The protection rail shouldn't be damaged or distorted by outside force during running.
- (3) Stipulate the entrance and exit of the protection rail, and make sure that the operators and other personnel cannot enter or exit through other passages.
- (4) Make sure that the hands, feet or any part of the body cannot enter the protection rail.
- (5) Please take the following measures at the entrance/exit of the protection rail.
- ① Install security door at the entrance/exit of the protection rail, and make sure that the emergency stop device starts automatically when the security door is opened.
- ② Indicate clearly that "Do not enter when the robot is running" and "Do not start the robot when operating" at the entrance/exit of the protection rail, and the operators should follow the regulations strictly.

If the protection rail hasn't been installed and the robot should be started for test running, it is necessary to allocate supervisors outside the restricted space to check the status of the robot to avoid operators entering the restricted space and ensure their safety.

1.11 Setting the motion space of robot

The space that the robot requires for operating is the operating space. If the motion space of the robot is larger than the operating space, please set the motion space lower to avoid colliding with other devices.



1.12 Prohibiting refitting the robot

It is prohibited to refit the robot, controller, teaching pendant and other optional parts.

1.13 Cleaning the tools

If the robot has welding torch or painting nozzle in the front, it is recommended to use automatic cleaning rather than manual cleaning.

1.14 Ensuring the illumination

Ensure the illumination required for safe operation.

1.15 Preventing flying off of clamped objects

The objects clamped by the robot may fly off or drop off. To ensure the safety of operators, it is necessary to take protective measures according to the size, weight, temperature, and chemical properties.

1.16 Pasting warning labels

Please paste the "Warning Label" in the robot components at prominent position such as the entrance/exit of the protection rail.



2. Operating precautions

Warning: It may cause serious casualties to touch the running robot. Therefore, please follow the precautions below while operating:

- ① When the robot is running or the motor is started, do not enter the restricted space of the robot.
- ② If it is necessary to enter the restricted space to process abnormalities, please start the emergency stop device and turn off the motor of the robot.
- ③ If it is necessary to operate in the restricted space for teaching and spot inspection, please take the measures in "4.2 Ensuring the safety of operators in restricted space".

2.1 Developing and effectively implementing "Operating Rules"

If it is necessary to operate in the restricted space for teaching and spot inspection, please develop and effectively implement the "Operating Rules" according to the precautions below.

- (1) The necessary steps to start the robot;
- (2) Robot velocity for teaching;
- (3) The contact mode in joint operation state (two or more operators);
- (4) The measures taken by the operators when abnormity occurs;
- (5) When the robot is stopped with the emergency switch, the necessary measures taken to confirm the release of abnormity and the security to restart the robot;
- (6) In addition to above rules, it is also necessary to take the following the measures below to avoid unexpected running of the robot or dangers caused by misoperation.
- ① The operating position and gesture of the robot should allow checking the status of the robot at any moment and evading immediately when any abnormity occurs.
- ② Measures to prevent interference.
- ③ The contact mode used by the operators of related machines.
- 4 Category and identification of abnormities.



Please develop the "Operating Rules" according to the type, installation location and operation of the robot.

2.2 Ensuring the safety of operators in restricted space

When operating in the restricted space of the robot, please take one of the following measures to ensure stopping the robot immediately once any abnormity occurs.

- (1) Start the emergency stop device immediately when abnormity occurs;
- (2) Only operators can enter the restricted space of the robot;
- (3) The operators in the restricted space should carry the emergency stop switch (or the emergency stop button for the multifunctional teaching pendant or miniature teaching pendant):
- (4) Please allocate supervisors outside the restricted space to check the status of the robot.

2.3 Spot inspection before guide and other operations

Before teaching, please check the following points, and take maintenance or other necessary measures when any abnormity occurs.

- (1) Whether the coating and packaging of external wires are damaged;
- (2) Whether the operating of robot is normal (whether there is abnormal sound or vibration when started);
 - (3) Whether the emergency stop device is normal;
 - (4) Whether the pipe leaks gas or oil;
 - (5) Whether there is barrier in or near the restricted space of the robot.

2.4 Release of residual pressure

Please release the residual pressure in the drive cylinder before decomposing air compression system or replacing parts.

2.5 Confirming the precautions during operating

The operators should move to outside of the restricted space to confirm the operating.

2.6 Precautions during automatic running

(1) Start the robot after confirming the following points:



- 1 There is no person in the restricted space of the robot.
- ② The multifunctional teaching pendant and tools are in specified position.
- ③ The indicators of the robot and related devices do not show abnormity.
- (2) During automatic running, check whether the AUTO indicator is lighted;
- (3) Occur abnormal situation.

When the robot or related devices have problems and it is necessary to enter the restricted space to operate, please stop the robot with the emergency stop device, and indicate "Operating" or similar message on the start switch to prevent other personnel operating the robot.

2.7 Maintenance precautions

- (1) Do not repair outside specified range;
- (2) Do not disassemble the interlock switch in any cases.
- (3) Only use approved parts for maintenance.

2.8 Daily spot inspection and periodic inspection

Please implement daily spot inspection and periodic inspection, and check whether the robot and related devices are normal before operating. If not, please take maintenance or other necessary measures immediately. Please record the details of periodic inspection and maintenance, and save the records for at least three years.

2.9 Safety regulations

Please follow the safety regulations of industrial robot. Please refer to the GB/T20867-2007 Industrial robot - Safety implementation specification.



3. SD series robot body

3.1 Basic structure of the robot

SD series robot features compact contour, small size and light weight, it is the most suitable robot for formation of small units and can be used to load and unload materials, sort and assembly with high speed and accuracy. Meanwhile, all cables of SD series robot are so built-in that can ensure flexible movement within a narrow space and installation in either grounded, wall-mounted or ceiling-mounted manner. Among all types of robots, SD500 model has its maximum working radius of 500mm, its wrist can endure a rated load of 1Kg and maximum load of 3Kg. Figure 3-1 is the actual picture of SD500 robot; Figure 3-2 is the figure of structure of SD series robot body; Figure 3-3 is the schematic diagram of each joint movement. SD700 model is such a robot that is elongated the forearm and large arm of SD500 model, its wrist endures same load with SD500 model and the maximum working radius is 700mm. Figure 3-4 and Figure 3-5 are respectively operating space diagram of SD500 and SD700 robot.



Figure 3-1 Real object of SD500 robot






Figure 3-2 Figure of structure of SD series robot body




Figure 3-3 Schematic diagram of kinematic axis of SD series robot






Figure 3-4 Working space of SD500 robot

- 12 -




Figure 3-5 Working space of SD700 robot

- 13 -



All cables of SD series robot are so built-in that can ensure flexible movement within a narrow space, the robot can be installed in grounded, wall-mounted or ceiling-mounted way through a connection between its pedestal and mounting face. The structure of pedestal installation can be referred in Figure 3-7 and the installation structure of wrist tool flange is shown in Figure 3-8.




Figure 3-6 Mounting holes on the pedestal




Figure 3-7 Flange mounting hole of wrist tool



3.2 Performance parameter of the robot

SD series robot features compact contour, small size and light weight, it is the most suitable robot for formation of small units and can be used to load and unload materials, sort and assembly with high speed and accuracy. Meanwhile, all cables of SD series robot are so built-in that can ensure flexible movement within a narrow space and installation in grounded, wall-mounted or ceiling-mounted manner. Table 3-1 provides main performance parameters of SD series robot. Among which, the relationship between the quality of wrist load and barycenter is shown in the figure.

Table 3-1 Performance parameter of SD series robot

| Model | | SD500 | SD700 |
|---------------------------|---------------------|-------------------------------------|-------------------------------------|
| Туре | | Vertical multi-joint | Vertical multi-joint |
| Number of axes | | 6 | 6 |
| Rated/Maximum loa | d | 1/3 kg | 1/3 kg |
| Maximum turning rad | ius | 500 mm | 700 mm |
| | J1 | ±170 | ±170 |
| | J2 | ±115 | ±115 |
| Range of movement | J3 | +40 ~ -220 | +40 ~ -220 |
| (°) | J4 | ±180 | ±180 |
| | J5 | ±125 | ±125 |
| | J6 | ±360 | ±360 |
| | J1 | 375 | 250 |
| | J2 | 375 | 185 |
| Maximum speed | J3 | 430 | 290 |
| (°/s) | J4 | 460 | 460 |
| | J5 | 460 | 460 |
| | J6 | 600 | 600 |
| Instantaneous maximum | J5 | 35 Nm | 35 Nm |
| allowable torque | J6 | 24 Nm | 24 Nm |
| Normal cycle time | | 0.6s | 0.6s |
| Repeat positioning accu | ıracy | ±0.015 mm | ±0.015 mm |
| Working temperatur | Working temperature | | 0 ~ 45℃ |
| Signal wires used by the | users | 0.14sqX16 line | 0.14sqX16 line |
| Position limitation prote | ction | Software limit Mechanical limit | Software limit Mechanical limit |
| Weight | | 26 Kg | 28 Kg |






Figure 3-8 The relationship between wrist load quality and load barycenter (A5 and A6 denote respectively the 5th and 6th axis, c and a represent respectively the distance of load barycenter to the 5th and 6th axis)

3.3 Electrical configuration of the robot body

SD series 6-axes robot is equipped with 6 motors and their corresponding encoders, which are connected respectively via 32-core gravity overload connector and 42-core gravity overload connector to the controller, two end interfaces on the robot body are shown in Figure 3-9. The definitions of connector pin can be referred respectively in Table 3-2 and Table 3-3.




Fig 3-9 Electric interface of the robot body



Table 3-2 Definition of 32-core power connector interface

| | | Power cable | |
|--------------|-------------|---------------------|---|
| Use of cable | Motor shaft | Definition of cable | Body interface 32-core power connector |
| | | U | 1 |
| | M1 | V | 2 |
| | | W | 3 |
| | | U | 4 |
| | M2 | V | 5 |
| | | W | 6 |
| | | U | 7 |
| | M3 | V | 8 |
| | | W | 9 |
| Power wire | M4 M5 | U | 10 |
| | | V | 11 |
| | | W | 12 |
| | | U | 13 |
| | | V | 14 |
| | | W | 15 |
| | M6 | U | 16 |
| | | V | 17 |
| | | W | 18 |
| | | BK+ | 19 |
| | M1 | BK- | 20 |
| | 140 | BK+ | 21 |
| | M2 | BK- | 22 |
| | N.40 | BK+ | 23 |
| Internal | M3 | BK- | 24 |
| contracting | N 4 4 | BK+ | 25 |
| brake | M4 | BK- | 26 |
| | | BK+ | 27 |
| | M5 | BK- | 28 |
| | N.40 | BK+ | 29 |
| | M6 | BK- | 30 |

Note: The motor on each shaft shall be provided with 4 cables: U, V, W and PE, PE cables of the motor are all connected on the housing of overload connector, which are only required to connect with UVW3 cable.



Table 3-3 Definition of 42-core power connector interface


| | | Encoder cable | |
|--------------------------|-------------|-------------------------|---|
| Application of the cable | Motor shaft | Definition of the cable | Body interface 42-core power connector |
| | | SD+ | 1 |
| | B 4.4 | SD- | 2 |
| | M1 | 5V | 3 |
| | | GND | 4 |
| | | SD+ | 5 |
| | M2 | SD- | 6 |
| | IVI∠ | 5V | 7 |
| | | GND | 8 |
| | МЗ | SD+ | 9 |
| | | SD- | 10 |
| | | 5V | 11 |
| Encoder cable | | GND | 12 |
| Encoder cable | | SD+ | 13 |
| | M4 | SD- | 14 |
| | | 5V | 15 |
| | | GND | 16 |
| | | SD+ | 17 |
| | M5 | SD- | 18 |
| | IVIO | 5V | 19 |
| | | GND | 20 |
| | | SD+ | 21 |
| | NAG | SD- | 22 |
| | M6 | 5V | 23 |
| | | GND | 24 |

Note:

- 1.Both ends of all shielded cables among encoder cables are connected on the housing of overload connector;
- 2. The encoder is provided with 6 cables; Besides 4 listed in the table, the rest 2 are battery cables, SD500 model is equipped with built-in batteries.



On the lateral side of robot pedestal air pressure and electric interface is reserved for hand-grasp tools, as shown in Fig 3-10, to facilitate wiring of hand-grasp tool cable from inside of the robot and prevent dangers caused by robotic winding of hand-grasp accessory cables.






Figure 3-10 Air pressure and cable interface reserved for hand-grasp tools




4. Controller of SD series robot

4.1 Introduction of the controller structure

SD series robot adopts 6-axes drive-control integrated controller QC600A newly developed by ADTECH, which is a tailor-made drive-control integrated system developed specially by this company for 6-axes robot. By revolutionary adoption of integrated design technology of motion control system and servo drive system, this product achieves real full-closed loop control between control system and servo drive system. QC600A integrates ADTECH's new generation of QX servo control technology and DSP motion control card technology and adopts advanced design means like distributed CPU and high-speed internal bus (IB) that demonstrates design achievements of high integration. Figure 4-1 is the controller cabinet appearance and machine body dimensional drawing; Figure 4-2 shows the external terminal plate. The list of QC600A controller configuration is shown in Table 4-1; the user is required to check whether or not all items configured are complete.








Figure 4-1 Controller cabinet appearance and machine body dimensional drawing



Figure 4-2 External terminal plate interface of the controller



Table 4-1 List of controller configuration

| Item Name | Illustration | Quantity |
|------------------------------|---|----------|
| QC600A | Drive and control integrated | 1 |
| Power plug | Power plug of main engine | 1 |
| Connecting line of the motor | 72-core overload connecting line | 1 |
| SRPT1000 demonstrator | Multi-functional and independent hand-held demonstrator | 1 |

QC600A features field line-saving mounted experience and intuitive human-machine interaction; In terms of teaching programming and operation, ADTECH and its parent company (Shanghai STEP Electric Corporation) form powerful alliance to co-develop operating software based on WinCE system, it is stable, reliable and has rich, powerful operation control statement, supports point-to-point, linear and circular motion, loop-jump uniform flow control, tool coordinate system and user coordinate system settings and I/O signal reading and output, the programming language is popular and understandable. Meanwhile, as to two types of operations: welding and palletizing, QC600A develops special instruction set to improve significantly the efficiency of programming and ensure safe, reliable operation. This product has many advanced functions, such as 6-axes linear interpolation, circular interpolation in 3D space, trajectory tracking, stable acceleration and deceleration and speed self-adaption of continuous motion trajectory and be applied in various occasions of six-axes robot. QC600A is compatible with a variety of brand absolute and incremental motors developed domestically and internationally, including motors branded SANYO, Panasonic and TAMAGAWA, the model of motor is optional and can drive directly 750W AC servo motor. Therefore, QC600A is suitable both for matching drive and control of SD series robot and control of other servo motors. Table 4-2 lists specification parameters of QC600A drive-control integrated controller.



Table 4-2 List of specification parameters of QC600A drive-control integrated controller

| | ē. | | | |
|---------------|------------------|-------------------------------|--------------|---|
| | Item | | | Model |
| | Model | | | QC600A |
| | | Display | | 8 inch |
| | | | | Manual data input(coordinate value |
| | Teach | ning method | 4 | input) |
| | 1 0001 | iii ig i i ioti iot | • | Teaching of orthogonal |
| | | | | and joint coordinate |
| | Input of traje | | amming | SR language |
| Demonstrator | | nguage | | 0 0 |
| | Da | ata wire | | 5M |
| | | Size | | 400 mm× 250 mm ×70 |
| | | | | mm(Demonstrator) |
| | | Veight | | Approximate 2Kg |
| | Elec | tric source | | 24V DC |
| | Data | exchange | | USB |
| | | Number | of control | 6 axes |
| | | ax | ces | |
| | | Type of servo motor | | AC servo motor |
| | | | | (SANYO, Panasonic, TAMAGAWA and |
| | | | | ADTECH servo motors) |
| | | | _ | Protocol servo |
| | | Supportin | g encoder | encoder(incremental/absolute), |
| | Axial-controlled | | | AB dual phase encoder |
| Drive control | function | Position co | ontrol cycle | 8K/16K |
| integrative | | Motion/servo control function | | Linear interpolation, circular |
| machine | | | | interpolation, continuous trajectory, |
| | | | | trajectory smoothness, acceleration and |
| | | | | deceleration of various kinds, etc. |
| | | Coordina | te system | Joint coordinate system, rectangular |
| | | Linit cott | ing of the | coordinate system |
| | | | ition | Degree, mm |
| | | | amming | Teaching page with robotic movements, |
| | | | nment | object-oriented programming statement |
| | | Storage | e means | Memory on board |
| | | Standard | IO input | 48 lines |
| | | IO | IO output | 48 lines |
| | External | External | | 3 pieces(dual line and DSP, single line |
| | input/output | communic | RS-232 | and X86 core board) |
| | | ation | RS-485 | 1 |
| | | 30011 | 1.00 | ' |



| | | Ethernet | 3 |
|-------|---------------------------------|----------|----------------------------------|
| | | USB(2.0) | 2 |
| | External dime | ension | 550mm ×307mm × 213mm(controller) |
| | Weight | | 17 Kg |
| | Power cal | ble | 1.5M |
| | Electric sourc | e used | 220V AC/50~60 Hz |
| | Capacity fa | ctor | 3KW(single-axis output≤750W) |
| Basic | Atmospheric p | ressure | 86Кра \sim 106Кра |
| size | Operating temp | perature | 0~40℃ |
| | Storage and tra temperatu | • | -10~65℃ |
| | Operating temp | perature | 20% ~ 90% RH |
| | Storage and transitive humidity | • | 10% ~ 95% RH |

4.2 Extended port of the controller

QC600A drive and control integrative machine is equipped with 48 lines of I/O inputs and I/O outputs. As an old saying goes that "keep one's eyes and ears open", this machine can be used to improve substantially external cooperative ability. Open the front panel of QC600A machine, I/O panel is placed on the topside of electrical cabinet, the customer may use extended port as required.

4.3 Port of controller over-load connector

QC600A is connected to robot body through 72-core overload connector, which includes power wire powering servo motor, encoder wire used to connect motor encoder and brake wire used for switch locking. As QC600A is compatible with multiple servo motor brands, the definition of 72-core overload connector port in QC600A machine is provided here in order to facilitate electric connection as per the brand of motor used by the users. Here the definition of 72-core overload connector in QC600A is given, as shown in Figure 4-4.





The above is the schematic diagram of overload connector and metal contact pin

Encoder line

| PCBA | Defin ition | 72-core overload connector | Encoder line |
|------|----------------|----------------------------------|-----------------|
| | GND | 49 | |
| М1 | 5V | 55 | |
| IVI | E1- | 53 | |
| | £1+ | 51 | |
| | GND | 50 | |
| M2 | 5V | 56 | |
| IVIZ | E2 | 54 | |
| | 1:2+ | 52 | |
| | GAD | 57 | |
| 142 | 5V | 63 | |
| МЗ | E3- | 61 | |
| | E3+ | 59 | |
| | GND | 58 | |
| M4 | 5V | 64 | |
| IVI4 | E4- | 62 | |
| | E4+ | 60 | |
| | GND | 65 | |
| M5 | 5V | 71 | |
| CIVI | F.5- | 69 | |
| | £5+ | 67 | |
| | GND | 66 | |
| M6 | 5V | 72 | |
| IVIO | E6- | 70 | |
| | £6+ | 68 | |
| | PE | housing | |

Power line


| PCBA | Defin ition | 72-core overload connector | Power line |
|------|----------------|----------------------------------|---------------|
| 2000 | U | 1 | |
| M1 | V | 2 | |
| | W | 3 | |
| | U | 4 | |
| M2 | ٧ | 5 | |
| | W | 6 | |
| МЗ | U | 7 | |
| | V | 8 | |
| | W | 9 | |
| | U | 10 | |
| M4 | ٧ | 11 | |
| | W | 12 | C. |
| | U | 13 | |
| М5 | ٧ | 14 | |
| | W | 15 | |
| | U | 16 | |
| М6 | V | 17 | |
| | W | 18 | ļ |
| | PE | Housing | |

Brake line

| Defin ition | 72-core overload connector | Brake line |
|----------------|----------------------------------|---------------|
| GND | 25 | |
| GND | 26 | |
| GND | 27 | |
| GND | 28 | |
| GND | 29 | |
| GND | 30 | |
| Relayl | 31 | |
| Rolay2 | -32 | |
| Relay3 | 33 | |
| Relay1 | 34 | |
| Rolay5 | 35 | |
| Relay6 | 36 | |

Metal contact pin used in the power line: CDMA-0.7 Metal contact pin used in the encoder line and brake line: CDMA-0.3

Figure 4-4 Definition of 72-core overload connector



5. Demonstrator of SD series robot

Usually SD series robot finishes predetermined motions through its controlling of robot body. The hand-held box consists of keys and buttons used for manually operating robot body and preparatory working procedures.

5.1 Illustration of front panel



Figure 5-1 Front panel of the demonstrator

5.1.1 Illustration of hand-held press key and display

| Press key | Illustration |
|-----------|--|
| | 【A/Lock/M】:Key Switch, it is used for mode conversion among 3 |
| | modes: A(Auto), Lock(Lock) and M(Manual), PC can control |
| | system only in Lock mode. |
| | 【STOP】:Emergency Stop Key, it is used in emergencies caused |
| | by possible risk of collision between the robot and peripheral |
| | equipment during operation, and can also be used to switch off |
| | "Motor Enable" and turn off [FN] indicator lamp. |



| F1 F2 F3 F4 | 【Reserve Functional Key】: This key can be re-defined on the spot as required. |
|-----------------------------|--|
| JOG | 【JOG】: This key is used to switch the robot's jogging coordinate system. |
| SINGLE | 【SINGLE STEP】: This key is used to switch the robot's program running mode and achieve loop interchange among 3 modes: CONTINUOUS, SINGLE-STEP and MOVING SINGLE STEP. |
| V - | 【V-/V+】:This key is used to adjust the robot's operating speed. |
| Shift | [Shift]: This key is used to shift compound key. If this key is not pressed, the line under the compound key is valid; If this key and compound key are pressed simultaneously, the line above this key is valid. |
| ADDITIONAL | 【ADDITIONAL AXIS】 : When the robot is equipped with additional axes, press this key and ADDITIONAL AXIS 47 is displayed in the jogging status area on the right of the demonstrator, the content of display has something to do with the number of additional axes. |
| SINGLE ERROR CLEARING | 【SINGLE ERROR CLEARING】:Clear one error. |
| All ERROR CLEARING | 【All ERROR CLEARING】:Clear all errors. |
| ENABLE | 【ENABLE】: This key is used to enable the robot in AUTO/EXTERNAL AUTO mode. |






[STOP]: This key is used to stop robotic operation.



START: This key is used to start robotic procedure.





[USER SETTING]: User management (user's log-in, obtaining and granting of control right), user edit (user edit, create and delete operations).



【ENGINEERING MANAGEMENT】: This key is used to conduct editing operation on the engineering (create, delete and copy, etc.) and administrative operation (load, close and open), editing operation (create, delete and copy, etc.) on the procedures; Display current procedures being loaded or opened.



[VARIABLE MANAGEMENT]: This key is used to maintain variables of demonstrator programs and provide functions such as variable display, correction, creation, copying, cutting, pasting, deleting and renaming as well as demonstration of type, variables of the robot's positions.



| INFO | 【INFORMATION】: This key provides quick entry into current error check page of the robot. |
|----------|--|
| 10 | 【IO】:This key provides quick entry into IO status check and compulsory page. |
| PROGRAM | 【PROGRAM MANAGEMENT】: This key is used to complete operating functions like program display and edit. |
| POSITION | 【POSITION】:This key provides quick entry into robot position check page. |
| LOG | 【LOG】:This key provides quick entry into existing error check page of the robot. |
| Tab Esc | 【Up/Down/Left/Right key】: This key is used to move cursor both vertically and horizontally during input. |
| Tab | 【Tab】: Deactivated |
| Esc | 【Esc Key】:Deactivated |
| Enter | 【Enter】: It is used to confirm input. |

グロアモビー A かみ Operation Instructions of SD Series 6-axis Robot

5.2 Illustration of rear panel



Figure 5-2 Rear panel of hand-held box

5.2.1 Explanation of three-position switch

This switch refers to the buttons at both side of the demonstrator body, as shown in Figure 5-2. This is an enable switch in the manual mode; the demonstrator is equipped with three sections of ON/OFF switch key. If the key is not pressed, the robot's brake is closed and in OFF status; Press this key gently to enable the robot and open the brake (with clicking sound), in such circumstance manual operations may be conducted to switch to ON status. Keep pressing this key until it is power-off, at this moment the brake is closed and in OFF status.



- 1. The robot is not permitted to operate if the enable switch is not in ON status.
- 2. If the enable switch is in OFF status (by loosening the hand or compulsory pressing) during hand operation, the motor is closed and in OFF status.



6. Robot Installation

6.1 Ensuring appropriate installation environment

When installing the robot body and controller, make sure that the use environment is identical to each item in the "1.Install Considerations" in Chapter 1 "Robot Installation and Maintenance". If the installation environment isn't appropriate, it is not possible to exert the performance of the robot, and also will shorten the service life of the machine, or even cause serious accidents. Table 6-1 summarizes the installation environment and conditions parameters of the robot body. For the installation of the robot body, please refer to Figure 6-1, and prepare the mounting rack with sufficient rigidity.

Table 6-1 Installation environment and condition of the robot

| Item | Environment & condition |
|----------------------------------|---|
| Flatness of installation bench | 0.1 / 500mm |
| Rigidity of installation bench | Steel material |
| Installation direction | Ground installation, hanging mounting, lifting |
| Ambient temperature | Operating: 0~40℃; storage & transportation: -10~60℃ |
| Llumiditu | Operating: <90% (no condensing); |
| Humidity | Storage & transportation: <75% (no condensing) |
| Vibration | Operating: <4.9 m/s2 (0.5G); |
| VIDIALIOIT | Storage & transportation: <29.4 m/s2 (3G) |
| | No inflammable gases or liquids ·No acid, alkaline and |
| | other corrosive gases ·No mists such as sulfur cutting |
| | liquid and milling liquid No large transformer, large |
| Cofe in stallation any image and | output high frequency oscillator, large contact, electric |
| Safe installation environment | welder and other electromagnetic interferences. |
| | ·No metal chips and other conductive substances. |
| | No mists such as cutting liquid and milling liquid. |
| | No water, oil, or scattered chips. |
| | ·Ensure sufficient spot inspection and disassembly |
| | space. |
| | ·Reserve wiring space in the rear of the robot |
| Operating space | (standard: >190mm; dust-proof, mist-proof and |
| | cleaning > 230mm); do not apply the weight of the cable |
| | on the connector directly; fix the wiring on the installation |
| | surface or beam. |
| Installation condition | D type grounding (resistance <100Ω) |





Figure 6-1 Mounting rack of typical robot body



Attention:

- ① Do not weld the electrical devices (including the robot). The current passing through the motor encoder and the controller is too high, and may cause failure. If the welding is required, please disassemble the robot and the controller first.
- 2 The robot will apply large counterforce on the installation bench when it is operating in high velocity. To avoid the bench vibrating or deviating due to counterforce, the bench should have sufficient rigidity. It is also an effective method to connect other heavy devices to the robot bench.
- ③ When the robot is operating, the bench may send resonant sound (hoot). When the resonant sound is increased, please improve the rigidity of the bench or decrease the velocity of the robot.



6.2 Installation method of the robot body

[1] Installation of the robot body

The installation operations of the robot body can be referred to steps listed as follows, we hereby explain on the condition that the mounting seat of the robot is prepared well and on which screw holes have been bored for fixation of the robot.

- Step 1 Check if the package is in good condition, open the packing box to ensure whether or not the robot is intact;
- Unscrew clamping screw to take down the robot body from bracket Step 2 mount of the wooden case:
- Move the robot onto the bench of the robot, align each mounting Step 3 hole to fix temporarily with 4 screws;
- Fix the robot with 4 screws(M10×25 mm) and flat washer; Step 4
- Fastening torque of the screw: 50 ± 5 N·m. Step 5



- (1) Safety Precautions must be read carefully when the robot is moved and installed:
- (2) The arm of the robot shall be supported to prevent tilting when fix screws are unscrewed.
- (3) Installation must be operated by at least 2 people. The weight of SD series robot body is about 28kg;
- (4) The operators must wear safety helmet, shoes, protective goggles and gloves.

[2] Ground connection of the robot body

Over 5.5 mm² wiring is required for the earth terminal of robot body in ground connection.

Note: The earth wire and electrode shall use special products, which shall not be combined to use with other electric, powered and welding machines.

6.3 Installing method of robot controller

Move the robot controller to the proper position of mounting table, and plug the



heavy-duty connector male of cables connecting between the robot body and controller to the corresponding female on the controller.

6.4 Connection between robot body and controller

Robot body and controller will be delivered upon matching debugging, and there is a corresponding number on the nameplate. In case of purchasing more than one robot, do not exchange the combinations of robot body and controller.

Note: The serial number of robot body and controller shall be the same combination.

6.5 Electrical wiring and air tubing methods of robot body

For the electrical wiring and air tubing of jigs and tools installed in the robot wrist, refer to the empty area reserved on the robot body for installation.

6.6 Installing method of work fixture

SD series robot wrist joints are arranged with tool flange mounting holes. Users are required designing the flanges of working fixture. It is to recommend M3 fixing screws to mount the grippers, suction cups or other tool on the tool mounting holes. There's air inlet, outlet and corresponding cable head reserved for the grippers in the SD series robot, as shown in Figure 3-10, but these shall be done for the convenience of internal alignment, while avoiding danger due to the wound of tool accessory with the robot, so users are required making connections according to their needs.



7. Robot maintenance

7.1 Category and Objective of Maintenance Spot Inspection

Please perform the maintenance spot inspection described in the table below.

Table 7-1 Category and Objective of Maintenance Spot Inspection

| No. | Category | Objective | |
|-----|-----------------|---|--|
| 1 | Daily | To use the robot properly, please perform spot inspection every day before operating. | |
| 2 | Three months | To maintain the precision of the robot and avoid failures caused by overheating of the controller, perform the spot inspection every three months. | |
| 3 | Six months | To avoid burning and damage that may cause major accidents, perform spot inspection for the rotary and sliding parts of the robot every six months. | |
| 4 | Two years | Spot inspection of synchronous belts | |



Attention

The maintenance spot inspection is performed in the motion space of the robot mostly. Since the probability of accidents is high, please follow local laws and regulations and ask qualified personnel to operate. Before operating, please read "1. Safety Precautions" and "2. Operating Precautions" in chapter I and this chapter carefully.

7.2 Operation matters of spot inspections

The spot inspections can be conducted in daily, 3-month, 6-month and 2-year manners. Please complete the spot inspections based on the particulars as listed in tables below.

Table 7-2 Daily Spot Inspection

| No. | Spot inspection position or running | Power status of the controller | Spot inspection method | Standard | Treatment of problem |
|-----|-------------------------------------|--------------------------------|------------------------------|-------------------------------------|---------------------------|
| 1 | Connectors and connected objects | OFF | Visual | No loose, pulling off or dirt | Insert normally and clear |

グロアモビー (A) Operation Instructions of SD Series 6-axis Robot

| 2 | Cables and external cable of the robot | OFF | Visual | No damage or crack | Repair, replace |
|---|---|-----|---------------------------------|--|----------------------------|
| 3 | Multifunction demonstrator | ON | Visual | Display | Repair, replace |
| 4 | Emergency stop button of multifunction demonstrator | ON | Press the emergency stop button | Emergency stop | Repair, replace |
| 5 | Motor ON LED in robot body | ON | Visual inspection | LED lights up when the motor is ON | Spot inspection and repair |

Table 7-3 3-month spot inspection

| No. | Spot inspection position or running | Power status of the controller | Spot inspection method | Standard | Treatment of problem |
|-----|--|--------------------------------|--|---|--|
| 1 | Fixation of base screw of robot | OFF | Determine the tightening torque with torque wrench | No specified torque loosened: 35 ± 8N·m | Fastening with the predetermine d torque |

Table 7-4 Yearly spot inspection

| No. | Item of spot | Power status of the controller | Spot inspection method | Standard | Treatment of problem |
|-----|----------------------|--------------------------------|---|---|---|
| 1 | Encoder batteries | OFF | Measure battery voltage with multimeter | The battery voltage is not lower than 3.2V | Replace the 3.6V battery |
| 2 | Robot structure | OFF | Visual inspection | No damage to the structural surface, and no significant gap between motion axle | Contact our customer service department for maintenance |



Chapter 2 Basic Operation

1. Changes in specification of robot

1.1 Meaning of changing robot specifications

The software that controls the manipulator uses the motion space of the manipulator as the top limit. In this space, the motion limit can be determined freely. The motion limit in software is called software limit, and changing standard settings is called changing manipulator specifications. To avoid interference with other device and entangling of wiring and pipes of the fixtures, it is required to set appropriate motion limit.

1.2 Software limit

1.2.1 Meaning of software limit

Software limit refers to determining the robot movement range limit by software. The robot is active only after entering the range set by the software limit. The mechanical movement limit is called manipulator end which is set by the mechanical stop. All A1, A2, A3, A5 and A6 axes of SD series of robots exist with mechanical terminal limit with buffer. Software limit is set at the slightly front position of the manipulator end as shown in the figure below during factory leaving, so as to prevent conflict with the mechanical stop. During manual operation and automatic movement of the robot, when it reaches the software limit, there will be certain error message displayed (see the software operation description for the details), with the running stopped. Software limit is separately set on the positive direction side and negative direction side of the movement range of all axes. Soft limit on the positive direction side is called positive-direction software limit; and soft limit on the negative direction side is called negative-direction software limit.






Fig. 1-1 Schematic diagram of movement range of software limit of the robot

1.2.2 Setting value of the software limit during factory leaving

Currently the setting value of the software limit during factory leaving of SD series is the movement range value of each axis.

1.2.3 Change of the software limit

Please change the software limit and narrow the movement range when the robot interferes with other device, and also when the air piping and wring for fixture jib is stretched due to robot movement.

Attention: During changing software limit, the movement range of the robot to set must be the range within the initial value.

1.2.4 Notes during changing software limit

- 1) Please confirm the movement range of the robot in the actual operating environment.
 - 2) Please note not to mistake the unit.
- 3) Situation of robot not running will occur if wrongly narrow the movement range to be too small.

1.2.5 Steps of changing the software limit

Change of the software limit of SD series of robots is completed via the special



configuration software RobotConfig through which the configuration file (.xml) is created to finally cover the old file in the controller. Double click RobotConfigure.exe to open the robot configuration software as shown in Fig. 1-2.




Fig. 1-2 Robot configuration main interface

Area 1 in the figure is the menu bar, including Robot, Aux Axes, Axis Coupling, Base&ToolTransfromation, Settings, JointLimits and AuxJointLimits, wherein, JointLimits is used to configure the software limit of the robot axes, invert direction or not and the maximum dynamic information (including maximum velocity, limited velocity, maximum acceleration, maximum deceleration and maximum jerk). Area 2 in the figure is the interface area which displays various configuration information and will be detailed successively below. Each menu page in Area 1 in the figure is described as below:

- Robot: for configuring basic parameters of the robot
- AuxAxes: for configuring the additional axes system of the robot
- Axis Coupling: for configuring the coupling parameters of the robot axes
- Base&ToolTransfromation: for configuring the robot base coordinate system and tool coordinate system
- Settings: for configuring the robot movement parameters
- JointLimits: for configuring the robot axis limit
- AuxJointLimits: for configuring the additional axis limit



Attention:

- 1. If only partial information is completed configuration and saved during the configuration, and the software is closed, then reconfiguration is required during next configuration. The software temporarily does not feature the file loading function, thus reconfiguration is required per time;
- 2. The Save button is in lower right corner of "AuxJointLimit" interface. After click of Save, the software automatically creates XML file of the configured information at a time. Note that the file name to save must be the default name;
- 3. As there are many configuration parameters of the robot and partial parameters involve the robot structure and running performance, such shall not be modified without authorization. Please contact the customer service personnel for robot of our company for conducting configuration if needed.

There are many configuration parameters of the robot, and before factory leaving of the product, all parameters have been completely configured and imported to the controller without requiring users for configuration. Only software limit configuration is introduced here. Please contact our company for configuring other parameters and having professionals conduct the operation. Configuration operation steps of software limit are as below:

- 1) Click "JointLimit" on the menu bar to pop up the interface for configuring robot axis limit as shown in Fig. 1-3; meaning of each physical quantity is as below:
 - SW limit negative: negative limit of the axis;
 - SW limit positive: positive limit of the axis;
 - Max velocity: maximum velocity, unit: units/s;
 - Reduced velocity: maximum limited velocity, unit: units/s;
 - Max acceleration: maximum acceleration, unit: units/s²;
 - Max deceleration: maximum deceleration, unit: units/s²;
 - Max jerk: maximum jerk, unit: units/s³;
 - Invert direction: invert direction or not. Invert direction means that actual rotation of the robot axis is opposite to the axis direction in "Robot" configuration interface. If the actual rotation of the robot axis is opposite to the axis direction in "Robot" configuration interface, then this check box shall be selected.








Fig. 1-3 Configuration interface of robot axis limit

- 2) Modify the values of SW limit negative and SW limit positive of each axis as required, and click the Save button in lower right corner of "AuxJointLimit" interface to create RobotParameter.xml file;
- 3) After click of Save, the software automatically creates XML file of the configured information at a time. Note that the file name to save must be the default name;
- 4) Connect local computer with the network interface 1 (the interface in lower left corner of the controller) on the controller;
- 5) Enter the following content on the computer address bar: ftp://192.168.39.220/, and click "Enter" on the keyboard to pop up the interface as shown in the figure below;

グロアモビー (A) Operation Instructions of SD Series 6-axis Robot



6) Double click ConfigureFiles folder in ftp to pop up the figure as shown in the figure below




7) Then replace the RobotParameter.xml file therein with the new file.



2. Status Bar of the Teaching Box

The status bar of the teaching box is mainly used to intuitively display some current internal statuses of the robot.



Schematic diagram of the status bar




Fig. 2-1 Layout of the status bar

2.1 Running mode


Operation mode: three in total, controlled via key switch.

Manual mode: the robot can be controlled to move by hand, in a relatively slow velocity, as shown in the figure below



Automatic mode: the robot automatically runs in a relatively fast velocity, as shown in the figure







External automatic: the robot is controlled to move by external equipment, which is suitable for engineering project, as shown in the figure



2.2 Enabling status

Function: for viewing if the robot is enabled.

means the robot enabling is off.



means the robot enabling is on.



2.3 Program running status

The program running status includes three statuses (Run, Pause and Stop).

means the robot is in Run status, as shown in the figure Icon



Icon means the robot is in Pause status, as shown in the figure





2.4 Program running mode

The program running mode includes three modes (Continuous, Single-step, and Movement single-step)

Icon The means the robot running mode is Continuous, as shown in the figure



Icon means the robot running mode is Single-step, as shown in the figure




Icon means the robot running mode is Movement single-step, as shown in the figure




2.5 Welding simulation

Icon means the robot conducts welding simulation, as shown in the figure








2.6 Emergency stop button status

means the emergency stop button is not pressed, as shown in the figure



2.7 Reference coordinate system

It is used to display the reference coordinate system of the current robot system. Switching of the reference coordinate system is required to be set in the program. The figure below shows switching of different coordinate systems. World coordinate system:





Custom coordinate system:



2.8 Tool

It is used to display the internal tool of the current robot system. There are two ways to set the robot system tool: set in the robot program or set through the tool setting drop-down box in the Robot Position interface. The figure below shows switching of different tools.

Status of no tool:




Custom tool:



2.9 Velocity

It is used to show the current robot running velocity parameter. There are three ways to set the velocity: set in the program, set through the "Velocity setting" in the Robot Position interface, or set through the panel buttons "V+" and "V-". The figure below shows different velocities:





2.10 Alarm information display

It is used to display the internal alarm information (three kinds: error, alarm and message) of current robot system, as shown in the figure



2.11 Alarm information confirmation button

It is used to confirm the internal alarm information of the robot system. The robot can be enabled again only after all internal alarm information of the system is confirmed.





3. Operation of the Function Interface

3.1 Setting interface

3.1.1 Description of the user authority

User groups are specified here as four groups: Low Level, Middle Level, High Level and Administration, corresponding to 1, 2, 3 and 4 in the Group column in the following table. 1 in Control authority column means requiring control authority, and 0 means requires no control authority. User authority is described as below:

- ➤ Administration>High Level > Middle Level > Low Level
- The higher level authority can conduct operation of the lower level authority.
- Description of authority of Low level users:

| Level 1 module | Level 2 module | Group | Control authority |
|-----------------------------|--|-------|-------------------|
| 1. Status bar | 1.1 Status bar display | 1 | 0 |
| 2. Error, alarm and | 2.1 Page display | 1 | 0 |
| message display | 2.2 Information screening display | 1 | 0 |
| 3.Report interface | 3.1 Page can be displayed or not | 1 | 0 |
| display | 3.2 Information screening display | 1 | 0 |
| 4. Robot Position interface | 4.1 Page display 4.2 TCP displays selection of reference coordinate system | 1 | 0 |
| 6.IO display | 6.1 Page display | 1 | 0 |
| 7. System | 7.1 User login screen display | 1 | 0 |
| management setting | 7.2 User login | 1 | 0 |
| screen | 7.3 Control authority be released | 1 | 0 |
| | 7.4 Page display of current login user | 1 | 0 |



| | 7.5Interface display of version information | 1 | 0 |
|-------------------------------|---|---|---|
| | 7.6 Interface display of | 1 | 0 |
| | Reset/Report | | |
| | 7.7 Interface display of Sys | 1 | 0 |
| | screen | | |
| 8. Variable | 0.4 Day at 15 at 15 | 4 | |
| | 8.1 Page display | 1 | 0 |
| monitoring and editing screen | 8.9 Variable data display | 1 | 0 |
| | | | |
| 12. Project interface | 12.13 Program directory display | 1 | 0 |
| | 12.14 Display of loaded program | 1 | 0 |
| | 12.15 Display of opened | 1 | 0 |
| | program | | |
| | 12.16 Page display | 1 | 0 |
| 14. Peripheral | 14.1 Interface switching button | 1 | 0 |
| button | | | |

• Description of authority of Middle Level users

| Level 1 module | Level 2 module | Group | Control authority |
|---------------------|--------------------------------------|-------|-------------------|
| 1. Status bar | 1.1 Confirm error, alarm and message | 2 | 1 |
| 2. Error, alarm and | | | |
| message display | 2.2 Confirm single piece | 2 | 1 |
| | 2.4 Confirm all information | 2 | 1 |
| 4. Robot Position | | | |
| interface | 4.2 Set jog coordinate system | 2 | 1 |
| menace | 4.3 Set override | 2 | 1 |

グロアモビー (A) Operation Instructions of SD Series 6-axis Robot

| 12. Project | 12.9 Load | 2 | 1 |
|---------------------|---------------------------|---|---|
| interface | 12.10 Open | 2 | 1 |
| | 12.11 Kill program | 2 | 1 |
| | 12.12 Close program | 2 | 1 |
| | | | |
| 13. Program editing | 13.1 Page display | 2 | 0 |
| interface | 13.5 Program running mode | 2 | 1 |
| | | | |
| 14. Peripheral | | | |
| button | 14.2 Operation mode | 2 | 1 |
| | 14.3 MOT | 2 | 1 |
| | 14.4 jog | 2 | 1 |
| | 14.5 step | 2 | 1 |
| | 14.6 v- v+ | 2 | 1 |
| | 14.7 start | 2 | 1 |
| | 14.8 stop | 2 | 1 |
| | 14.9 Axis+, and axis- | 2 | 1 |
| | 14.10 2nd | 2 | 1 |

• Description of authority of High Level users

| Level 1 module | Level 2 module | Group | Control authority |
|-----------------------------|------------------------------|-------|-------------------|
| | | | |
| 4. Robot Position interface | 4.4 Tool setting | 3 | 1 |
| IIILEITACE | | | |
| 5. Tool Manual | 5.1 Page can be displayed or | 3 | 1 |
| Alignment interface | not | | |
| | 5.2 Tool alignment | 3 | 1 |
| | 5.3 Enable tool alignment | 3 | 1 |
| | 5.4 Cancel tool alignment | 3 | 1 |
| | | | |



| | 6.2 DI (analog input) | 3 | 1 |
|-------------------|---------------------------------|---|---|
| | 6.3 Remove DI | 3 | 1 |
| | 6.4 D0 (forced output) | 3 | 1 |
| | 6.5 Remove DO | 3 | 1 |
| | 6.6 AI (analog input) | 3 | 1 |
| | 6.7 Remove AI | 3 | 1 |
| | 6.8 A0 (forced output) | 3 | 1 |
| | 6.9 Remove AO | 3 | 1 |
| 7. System | 7.11 Restart teaching box | 3 | 1 |
| management | 7.12 Restart controller | 3 | 1 |
| setting screen | | | |
| 8. Variable | 8.2 New variable | 3 | 1 |
| monitoring and | 8.3 Rename variable | 3 | 1 |
| editing screen | 8.4 Cut variable | 3 | 1 |
| | 8.5 Copy variable | 3 | 1 |
| | 8.6 Paste variable | 3 | 1 |
| | 8.7 Delete variable | 3 | 1 |
| | 8.8 Teach variable | 3 | 1 |
| | 8.10 Modify variable | 3 | 1 |
| 9.Positions | 9.1 Page display | 3 | 1 |
| interface | 9.2 Select variable | 3 | 1 |
| | 9.3 Teach variable | 3 | 1 |
| | 9.4 Select jog to position mode | 3 | 1 |
| | 9.5 Enable jog to position | 3 | 1 |
| | 9.6 Cancel jog to position | 3 | 1 |
| 10. Custom | 10.1 Page display | 3 | 1 |
| coordinate system | 10.2 Select variable of | 3 | 1 |
| | | | |



| | reference coordinate system | | |
|---------------------|-----------------------------|---|---|
| | 10.3 Select reference | 3 | 1 |
| | coordinate system | | |
| | 10.4 SETUP button | 3 | 1 |
| 11. Tool interface | 11.1 Page display | 3 | 1 |
| | 11.2 Select tool variable | 3 | 1 |
| | 11.3 SETUP button | 3 | 1 |
| | | | |
| 12. Project | 12.1 Rename project program | 3 | 1 |
| interface | 12.2 Delete project program | 3 | 1 |
| | 12.3 Paste project program | 3 | 1 |
| | 12.4 Copy project program | 3 | 1 |
| | 12.5 New program | 3 | 1 |
| | 12.6 New project | 3 | 1 |
| | 12.7 Import | 3 | 1 |
| | 12.8 Export | 3 | 1 |
| 42 Drogram aditing | | | |
| 13. Program editing | 13.2 MODIFY | 3 | 1 |
| interface | 13.3 New | 3 | 1 |
| | 13.4 Setpc | 3 | 1 |
| | 13.6 copy | 3 | 1 |
| | 13.7 paste | 3 | 1 |
| | 13.8 cut | 3 | 1 |
| | 13.9 remove | 3 | 1 |




Description of authority of Administration users


| Level 1 module | Level 2 module | Group | Control authority |
|----------------|-----------------------------|-------|-------------------|
| | | | |
| 7. System | 7.5 User management page | 4 | 0 |
| management | display | | |
| setting screen | 7.6 Edit user | 4 | 1 |
| | 7.7 New user | 4 | 1 |
| | 7.8 Delete user | 4 | 1 |
| | 7.13 Create (create report) | 4 | 1 |
| | 7.14 export (export report) | 4 | 1 |
| | 7.16 Modify and set IP | 4 | 1 |
| | connection | | |

3.1.2 User login


button and click "Setting" to enter the user management interface as shown in the figure



Select the user name as shown in the figure




Enter the password as shown in the figure






Check the control authority to obtain the authority, as shown in the figure



Attention: "Control Authority" is used to obtain and release control authority: when checked, it means that the control authority is obtained; when unchecked, it means that the control authority is released. If the control authority of current controller is obtained by other PLC, the "Control Authority" checking will be unavailable.


• Click Login to obtain the authority for operation. The interface after login is as shown in the following figure. When the username is displayed in "Current user", it means that the login is successful.






3.1.3 Adding user

Click User management, as shown in the figure






Select New as shown in the figure




Enter the username, password, confirm password, and select the user group information, as shown in the figure






Click OK to add new user, as shown in the figure



3.1.4 Editing user


To edit user, select the user to edit and click Edit, as shown in the figure






3.1.5 Deleting user

To delete user, click Delete, as shown in the figure




Click OK to successfully delete the user, as shown in the figure





3.1.6 Choosing language

Choose the language, as shown in the figure




3.2 IO monitoring

Click




button, as shown in the figure







Click "IO monitoring" to enter the initialization interface, as shown in the figure



Click the upper tabs in the interface 0 1 to enter different IO point interfaces, as shown in the figure









3.2.1 DI (digital input)

When IO monitoring is selected, DI is selected by default, as shown in the figure






Check Simulation in the DI window, and select the "OFF" or "ON" in the drop-down box of Setting, as shown in the figure



Input simulation will be switched on if "ON" is selected, as shown in the figure





① The ID, Name, Status, Setting and Simulation in the DI interface separately




means the ID No., name, status, input simulation setting and whether to switch on the input simulation of the DI.

- ② The range of DI is 0-31 which can be extended according to the actual situation. The DI can be designated a name according to the actual requirement.
- 3 DI input simulation setting Status displays current DI status, means that current DI is 1, and means that current DI is 0. Two options "ON" and "OFF" will be popped up when the drop-down box of Setting is clicked, separately corresponding to the "1" and "0" of DI status. E.g., when "ON" is clicked, it means that the input simulation status is set as "1".
- 4 Simulation column is used to control whether to conduct DI simulation: when the check box is checked, it means the input simulation will be conducted, and vice versa.


3.2.2 DO (digital output)

DO window is as shown in the figure





Forced DO is as shown in the figure




Attention:

- ① The ID, Name, Status, Setting and Forced in the DO interface separately means the ID No., name, status, forced output setting and whether to switch on the forced output of the DO.
- ② The range of DO is 0-31 which can be extended according to the actual situation. The DO can be designated a name according to the actual requirement.
- Status displays current DO status: means that current DO is 1, and means that current DO is 0. Two options "Forced ON" and "Forced OFF" will be popped up when the drop-down box of Setting is clicked, separately corresponding to the "1" and "0" of DO status. E.g., when "ON" is clicked, it means that the input simulation status is set as "1".
- 4 Forced column is used to control whether to conduct forced digital output: when the check box is checked, it means the forced output will be conducted, and vice versa.




3.2.3 Al (analog input)

Al is as shown in the figure



Simulation AI is as shown in the figure








- ① The ID, Name, Status, Setting and Simulation in the Al interface separately means the ID No., name, status, analog input simulation and whether to switch on the analog input simulation of the Al.
- ② The range of Al is 0-31 which can be extended according to the actual situation. The Al can be designated a name according to the actual requirement.
- 3 Status displays current Al data. Enter the data in the text box, and click "Confirm" button after the text box to complete simulation of the Al.
- 4 Simulation column is used to control whether to conduct Al simulation: when the check box is checked, it means the Al simulation will be conducted, and vice versa.

3.2.4 AO (analog output)

AO is as shown in the figure







Forced AO is as shown in the figure

3.3 Tool

key to pop up options of "Tool", "Coordinate system", and "Variable", Click as shown in the figure




Select the "Tool" for teaching, to enter the initialization interface, as shown in the figure



First select the tool variable needed teaching in the drop-down box of "Tool", and the numerical values of the tool will be displayed on left side of the interface; click "Setting" key to enter the interface for selecting the tool teaching method, as shown in the following figure:







Attention:

Tool variable teaching needs teaching in two parts: positions X, Y and Z of teaching tool; postures A, B and C of teaching tool. There are two methods of tool position teaching: one-point method and four-point method. There are two methods of tool posture teaching: one-point method and three-point method. Click "Cancel" or "Back" to return to the initial interface of coordinate system teaching; click "Next" to enter the specific coordinate system teaching interface.


3.3.1 Positions XYZ (one-point method) of teaching tool

First select the coordinate teaching method ("Teaching XYZ One-point method") in the above figure, and click "Next" to enter the following interface:






Select one tool that is known the posture, then move the robot to the expected position, and click "Teach" to complete the teaching; click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to previous step; click "Next" and it will enter to the next teaching interface as shown in the figure below:



Take down the known tool, replace with the tool needed teaching, then move the



robot to the teaching position in Step 1, and click "Teach" to complete the position teaching; click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to the interface for selecting tool teaching method; click "Next" and it will enter to the next teaching interface as shown in the figure below:




The left in the interface displays the coordinate system data after teaching; click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to the Step 2 interface of obtaining XYZ (one-point method) teaching; click "OK" and it will save the data and complete the tool teaching.


3.3.2 Positions XYZ (four-point method) of teaching tool

 Select the coordinate system teaching method ("Teaching XYZ Four-point") method") as shown in the figure






Click "Next" to enter the following interface, then move the robot to the expected position, and click "Teach" to complete the teaching of first posture; click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to the previous step as shown in the figure below:




Click "Next" to enter the next teaching interface as shown in the figure below:






- Approach the robot to the expected point in another posture, and click "Teach" to complete the teaching of second posture point. As shown in the figure, click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to the previous step.
- Click "Next" to enter the next teaching interface as shown in the figure below:




- Approach the robot to the expected point in another posture, and click "Teach" to complete the teaching of third posture point. As shown in the figure, click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to the previous step.
- Click "Next" to enter the next teaching interface.





- Approach the robot to the expected point in another posture, and click "Teach" to complete the teaching of fourth posture point. As shown in the figure, click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to the previous step.
- Click Next to enter the next interface as shown in the figure




The left in the figure displays the coordinate system data after teaching, and the lower part displays the absolute error between the four teaching points and the




actual points; click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to the previous step; click "OK" and it will save the data and complete the tool teaching.

3.3.3 Postures ABC (one-point method) of teaching tool




Select the coordinate system teaching method ("Teaching ABC One-point method") and click "Next" to enter the interface as below:






Attention:

- ① "Tool" column indicates the positive directions of "Z" and "X" axes of the coordinate system of the tool.
- 2 "World coordinate" column is used to confirm the alignment between the tool axes and World axes.
- ③ "Invert direction" column is used to confirm whether the axes are aligned with the positive axes or negative axes of the selected world coordinate system.
- The teaching result is as shown in the figure below




Based on the alignment relationship setting between the tool axes and world coordinate axes, move the robot to the alignment posture, and click "Teach" to complete the teaching of the point; click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to the interface for selecting the tool teaching method; click "Next" and it will enter the next teaching interface as shown in the figure below:






The left in the interface displays the coordinate system data after teaching; click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to the Step 1 interface of obtaining ABC (One-point method) teaching; click "OK" to complete the tool teaching.


3.3.4 Postures ABC (three-point method) of teaching tool



Select the coordinate system teaching method ("Teaching ABC Three-point method") and click "Next" to enter the following interface:




- First select the teaching direction: forward or invert direction of Z axis, forward or invert direction of ZX plane. Move the robot to certain reference point in the space, and then click "Teach" button to complete teaching of the first point, as shown in the figure above.
- Click "Cancel" to return to the initial interface of tool teaching; click "Back" to return to the previous step; click "Next" to enter the next teaching interface as shown in the figure below:




- Move the robot to certain reference point in the space, and then click "Teach" button to complete teaching of the second point, as shown in the figure above.
- Click "Cancel" to return to the initial interface of tool teaching; click "Back" to return to the interface for selecting the tool teaching method; click "Next" to enter the next teaching interface as shown in the figure below:






- Move the robot to certain reference point in the space, and then click "Teach" button to complete teaching of the third point, as shown in the figure above.
- Click "Cancel" to return to the initial interface of tool teaching; click "Back" to return to the interface for selecting the tool teaching method; click "Next" to enter the next teaching interface as shown in the figure below:



The left in the interface displays the coordinate system data after teaching; click "Cancel" and it will return to the initial interface of tool teaching; click "Back" and it will return to previous step; click "OK" to save the data information and complete the tool teaching.





Attention


- ① The ID, Name, Status, Setting and Forced in the analog output interface separately means the ID No., name, status, forced analog output and whether to switch on the forced analog output of the AO.
- ② The range of AO is 0-31 which can be extended according to the actual situation. The AO can be designated a name according to the actual requirement.
- ③ Status displays current AO data. Enter the data in the text box, and click "confirm" button after the text box to complete forced AO.
- 4 Forced column is used to control whether to conduct forced AO: when the check box is checked, it means the forced AO will be conducted, and vice versa.

3.4 Coordination system


to pop up the options of "Tool", "Coordination system" and "Variable" as Press

shown in the figure





Select coordination system to enter into the initial interface of the coordination system as shown in the following figure






Note:

- U Selection of user's coordination system: select the coordination system for teaching;
- ① Selection of reference coordination system: select reference coordination system for teaching coordination system. The type of the coordination system here include general user coordination system, "WORLD" coordination system and "ROBOTBASE" coordination system;
- (3) The display of TCP point on the user coordination system;
- 4 The display of TCP point on the reference coordination system.




Click on "Settings" to enter into the user coordination system for teaching to select the interface as shown in the following figure:




3.4.1 Three-point method (with original point)

Select the coordination system teaching method "Three-point method(with original point) and click on "Next" to enter into the interface as shown as below:




グロアモビース方米 Operation Instructions of SD Series 6-axis Robot

- Click "Teaching" button to complete the original point teaching of coordination system; click on "Cancel" to return to the initial interface of coordination system teaching; click on "Return" to return to the previous interface (coordination system teaching method selecting interface).
- Click on "Next" to enter into the next teaching interface as shown in the following figure:




- Firstly, select the axis (X, Y, Z) where the point for teaching locates, select the direction of the teaching axis (positive or negative), move the robot to the desired position and finally click on "Teaching" to complete the teaching of the second point of the Three-point method. Click on "Cancel" to return to the initial interface of coordination system teaching; click on "Return" to return to the previous step.
- Click on "Next" to enter into the next teaching interface as shown in the following figure:

グロアモビートの対策 Operation Instructions of SD Series 6-axis Robot




- Firstly, select the axis (XY, XZ, YZ) where the point for teaching locates, select the direction of the teaching axis (positive or negative), move the robot to the desired position and finally click on "Teaching" to complete the teaching of the third point of the Three-point method. Click on "Cancel" to return to the initial interface of coordination system teaching; click on "Return" to return to the previous step.
- Click on "Next" to enter into the next teaching interface as shown in the following figure:





What displays on the left side of the interface is the coordination system data XYZ after teaching; click on "Cancel" to return to the initial interface of coordination system teaching; click on "Return" to return to the previous step; click on "CONFIRM" to save data and complete the coordination system teaching.


3.4.2 Three-point method (without original point)



Select the coordination system teaching method "Three-point method (without




original point) and click on "Next" to enter into the interface as shown as below:




- Firstly, select the axis (X, Y, Z) where the point for teaching locates, select the direction of the teaching axis (positive or negative), move the robot to the desired position and finally click on "Teach" to complete the teaching of the first point of the Three-point method. Click on "Cancel" to return to the initial interface of coordination system teaching; click on "Return" to return to the previous step (coordination system teaching method selecting interface).
- Click on "Next" to enter into the next teaching interface as shown in the following figure:






- Firstly move the robot to the desired position and click on "Teach" to complete the teaching of the second point. In this way, an axis of the coordination system can be determined through the points determined in this and last steps. Click on "Cancel" to return to the initial interface of coordination system teaching; click on "Return" to return to the previous step.
- Click on "Next" to enter into the next teaching interface as shown in the following figure:




グロアモビース方米 Operation Instructions of SD Series 6-axis Robot


- Firstly, select the axis (X, Y, Z) where the point for teaching locates, select the direction of the teaching axis (positive or negative), move the robot to the desired position and finally click on "Teach" to complete the teaching of the third point of the Three-point method. Click on "Cancel" to return to the initial interface of coordination system teaching; click on "Return" to return to the second step interface of the three-point method teaching without original point.
- Click on "Next" to enter into the next teaching interface as shown in the following figure:




What displays on the left side of the interface is the coordination system data after teaching; click on "Cancel" to return to the initial interface of coordination system teaching; click on "Return" to return to the previous step; click on "CONFIRM" to save data and complete the coordination system teaching.



3.4.3 One-point method (hold the pose)



Select coordination system teaching method "one-point method (hold the pose)" and click on "Next" to enter into the following interface as shown as below:




Move the robot to the desired position, click on "Teach" button to complete the teaching of the original point position of coordination system and the coordination system pose remains unchanged; click on "Cancel" to return to the initial interface



of coordination system teaching; click on "Return" to return to the previous step (coordination system teaching method selecting interface).

Click on "Next" to enter into the next teaching interface as shown in the following figure:



What displays on the left side of the interface is the coordination system data after teaching; click on "Cancel" to return to the initial interface of coordination system teaching; click on "Return" to return to the previous step; click on "CONFIRM" to save data and complete the coordination system teaching.

3.5 Variable


to pop up the options of "Tool", "Coordination system" and "Variable" as Press

shown in the figure

3.5.1 Variable classification and notices

The variable is used to maintain the program variable data of demonstrator. It is as shown in the figure when selecting a variable









Note:

- $ext{ }$ The variable in the robot system is divided into four types: system variable, global variable, engineering variable and program variable.
- ② The program variables between different programs can be the same name.
- 3 The program variable under certain engineering cannot be named the same as the engineering variable of the engineering.
- 4 Any variable cannot be named the same as the global variable.
- (5) The name of the system variable is fixed, for example, "WORLD", "ROBOTBASE" AND "EASYS". And the system variable cannot be renamed or deleted.


3.5.2 Variable operation

Creation of variable. Select the desired variable type and click on "Create" as shown in the following figure:





Click on "Create" to pop up variable creation interface as shown in the following figure:






① The variable can be renamed but it is still subject to the rules of variable





naming mentioned in the last section;

- ② The left button in the above figure is used to select the large type of variable and the right side of the interface lists the specific variable types under the large type. What is shown in the above figure is the variable types under the corresponding "basic type". Input variable name and click on "CONFIRM" to complete the creation of variable. Click "Cancel" to cancel the creation and variable and quit the variable creation interface.
- 3 The variable type is divided into basic type, position type, coordination system tool type, dynamic smooth type, IO type and welding type which are as shown in the following figure separately























Copy of variable: select a variable, click on "Copy" button and the variable will be copied into the clipboard as shown in the figure




Cut of variable: select the variable which is not occupied by the program and this variable can be cut and pasted; the variable which is occupied by the program




cannot be cut but it will be judged if the paste is valid, if not, the paste will not be operated; the rule for cut is: the program variable can only be cut into under the engineering or the global situation. The engineering variable can only be cut into the global situation.

- Paste of variable: select a name of engineering or program and then it can be pasted from the clipboard under the engineering or program. A dialog box for change of variable name will appear when pasting.
- Delete of variable: the variable which is occupied by the program cannot be deleted as shown in the figure




Rename of variable: a selected variable can be renamed as shown in the figure:






Position variable teaching: select a position variable type (for example: ROBOTAXISPOS), move the robot to the desired position and then click on "Teaching" button to complete the variable teaching function, teaching the current position as shown in the figure:






Teaching finishes as shown in the figure:




3.6 Engineering

button on the left side of the demonstrator as shown in the figure Press the



 Single click on "Engineering" to enter into the engineering interface as shown in the figure.






Note:


"_global" means the global engineering. This engineering always exists and user cannot delete or rename it.

3.6.1 New Project


Click the "New Project" in the "File", as shown below.



Select "New Project" and the window pops up, as shown in figure below.



Enter the project name and click "OK", the new project is completed, as shown in Figure.




3.6.2 Copy Project

Select the project you want to copy, such as the "skl" in figure below, click the "Copy" in the "File", and then the project is copied to the clipboard, as the figure




below shows.




3.6.3 Paste Project

When the project is copied to the clipboard, choose the place where you want to paste, select "Paste" in the "File", and the following dialog box pops up prompting you to enter a new name. Click "OK" to complete the paste. As shown in figure below:






The figure below shows the status after copy and paste.



3.6.4 Rename Project


Select the project you want to rename, click "Rename" in the "File", and the dialog box as the figure below shows appears, at this time you need to modify the new name, and click "OK."



Following modifications appears for the project directory upon renaming, and




"test23" is modified as "test32".



3.6.5 Delete Project

Select the project you want to delete, click on the "Delete" in the "File". When the following dialog box appears, click "OK" and confirm to delete the project.






3.7 Program


3.7.1 New Program

Select the new project directory, and click the "New Program" in the "File", as shown in figure below.




Dialog box as the figure below shows pops up, then enter the program name, as shown in the following figure.





Click "OK", and new program is completed, as shown in figure below.




Note:

Editing operation is also available for the program (new, rename, delete, copy, etc.), which is similar with the edit operations of the project, so no detailed introduction will be given.

3.7.2 Load Program



First, you need to select the project that has been loaded in the project directory, and then click the "Load". If the program has been modified, and there will be prompted to save the program, as the figure shows.




Notes:

There's only one program being loaded at the same time. If the program A has been loaded, and if you want to load the program B, then you may load program B after closing the program A; in case of syntax error existed to the program to be loaded, there will be an error dialog box popping up to prompt the line where the statements are located, and enter into the open state interface of the program.

3.7.3 Open Program

First, you need to select in the program (not being loaded) in the project directory tree, and then click on the "Open", as shown in Figure:









"Open Program" allows only the program opening and viewing, but cannot run the program. If you run such program, the program shall be loaded.

3.7.4 Close Program

First, you need to select the opened programs in the project directory tree, and then click "Close" to close the program. As the figure shows




3.7.5 View Current Program



 Upon clicking the "Program", you can quickly access to the program interface that has been recently opened or loaded; as shown in the figure below.






3.8 Position

3.8.1 Position display


button at the left of demonstrator, as shown in the figure below. Press the




Click the "Position" and you can get the position information in different coordinate systems. TCP position display can be switched between two spaces, the



joint space and Cartesian space, as shown in the figures.



Cartesian position display of robot



Joint space position display of robot




① Reference coordinate system switching of TCP position: There're three



buttons located at the lower of interface, they are "World Coordinate System", "Base Coordinate System" and "Joint Coordinate System". Only click on the "Joint Coordinate System" button, then it will switch to joint space position. If you click on the "World Coordinate System" and "Base Coordinate System" button, it will switch to the Cartesian space position.


- 2 The "Reference Coordinate System" drop-down box in the right of the interface is used to customize the reference coordinate system selection. When the custom coordinate system as "gzt" is selected in the drop-down box, the button of the corresponding custom reference coordinate system in the lower of interface is displayed as "gzt", which means that if the additional axis is configured, there will be additional axis coordinate system option here.
- ③ TCP is displayed in three columns in Cartesian space, respectively the name, value, units; and the names are indicated as X, Y, Z, A, B and C; the numerical display accurate to two decimal places; the unit is mm (millimeters, corresponding to the X, Y, Z) and deg (degrees, corresponding to A, B, C).
- 4 TCP is displayed in three columns in the joint space position, they are name, value, unit and status, respectively; and the names can be A1, A2, A3, A4, A5 and A6; the numerical display accurate to two decimal places; the unit is deg (degrees); the status display shows the joint limit, measured in degrees.
- (5) If the robot is configured with additional axes, A7, A8, A9 ... shall be added to the above figure showing the additional axis of robot, and the robot can be equipped with up to six additional axes.





3.8.2 Velocity Settings

Click "Velocity Settings", and you can adjust the running velocity of the robot. The velocity settings are divided into 8 levels: 100%, 80%, 50%, 30%, 10%, 2inc, 1inc, 0.1inc. After selecting an appropriate velocity here (e.g. 10%), the velocity value display in status bar will changes accordingly. as the figure shows.






Attention:

- \bigcirc Velocity setting can also be done by pressing the v +, v- buttons on the panel.
- 2 The jog type corresponding to the velocity ending in "inc" is the incremental jog, and others are the continuous jog.

3.8.3 Settings of moving coordinate system

Click on the "Jog Coordinate System" button, and the settings dialog of jog reference coordinate system will pop up, respectively corresponding to the tools, joints, base coordinate system and world coordinate system. As the figure below shows:







Attention:

① After the jog reference coordinate system is set to "Tools", the right status bar of interface displays as TX, TY, TZ, TA, TB, TC, as shown in the figure;






② Setting the jog reference coordinate system to "Joint", the right status bar of interface displays as A1, A2, A3, A4, A5, A6, as shown in the figure;




3 Setting the jog reference coordinate system to the "Base Coordinate" System" or custom coordinate system, and the right status bar of interface displays as RX, RY, RZ, RA, RB, RC, as shown in the figure below;





Setting the jog reference coordinate system to "World Coordinate System", and the right status bar of interface displays as X, Y, Z, A, B, C, as shown in the figure below.




(5) If there's additional axis configured for the robot, click on the 2nd and the right status bar of the interface shows the additional information, such as axis A7, A8, A9 ..., and the number as displayed is connected with the




number of additional axle that are current configured.

3.9 Message

button at left of the demonstrator, as shown in the figure. Press the




Click "Info" and there displays the error alarm message of current robot failure. As the figure below shows:







- (1) Message data display: The occurrence time, ID number, description, as well as sources of message;
- ② Complete message display: Select a message, and the complete description of such message is displayed in the control located at lower of the interface;
- ③ Message screening display: Select the message type you want to display in the "Message Block " drop-down box at lower of the interface, in which All messages, Errors, Warnings, Info correspond to the message types as follows: all messages, error messages, alarm message and general message. As shown in the figure below:






4 Message confirmation:

Single Confirmation: First, select a message you want to confirm, and then click on the "OK" button to confirm the single piece of message, and such selected message will be disappeared in the interface.

Overall Confirmation: Click "Confirm all" to confirm all the messages, the all the messages will disappear from the interface. As shown in figure below:





Chapter 3 Advanced Programming

1 Jog operation of robot

1.1 Continuous jog

The continuous jog means that when hold down the jog button "+" and "-", the robot will continuously moving, and will stop upon releasing the button "+" and "-".

For the continuous jog, first you need to set the velocity (the velocity shall not end in "inc" after setting), and then determine whether the status bar on the right side displays the joint jog or Cartesian jog, rather than the jog icon of absolute position.

The reference coordinate system of continuous jog includes the joint and Cartesian reference coordinate systems (namely the "World Coordinate System", "Base Coordinate System" and custom reference coordinate system). The continuous jog reference coordinate system can be set in the pop-up box of "Jog" button in the robot interface; velocity setting can be done in three ways: First setting in the program, the second is setting by the "Velocity Setting" on the robot position interface, and the third is setting via the "V +" "V-" buttons of the demonstrator.

1.2 Incremental jog

In the incremental jog mode, the running route length of the robot is independent of the button "+", "-" hold-down time, but the number of pressing the "+", "-" buttons.

For the incremental jog, first you need to set the velocity (the velocity shall not end in "inc" after setting), and then determine whether the status bar on the right side displays the joint jog or Cartesian jog, rather than the jog icon of absolute position.

Similar with the continuous jog, the reference coordinate system of incremental jog includes the joint and Cartesian reference coordinate systems (namely the "World Coordinate System", "Base Coordinate System" and custom reference coordinate system). The incremental jog reference coordinate system can be set in the pop-up



box of "Jog" button in the robot interface; velocity setting can be done in three ways: First setting in the program, the second is setting by the "Velocity Setting" on the robot position interface, and the third is setting via the "V +" "V-" buttons of the demonstrator.

1.3 Jog of absolute position (not being enabled temporarily)

The absolute position jog is to enable the robot to move to a point in space in some ways ("PTP" or "Lin").


For the absolute position jog, first you need to switch the robot to the absolute position jog mode by pressing "Activate" button in the corresponding interface, and the icon will appear on the right status bar at this time. For the other specific settings, please refer to the instructions on the absolute position jog interface.

Run program

2.1 Manual mode


Under manual mode T2

Open the project screen and select the program (it is available if there's no loaded program in the red box on the upper side). As the figure shows







Click the "Load", as the figure shows.




Select the statement line you want to run, click SetPC, and the program will jump to the line you want to run. Enable on the three-position switch to select the way of movement, and hold down the "Start" button located at the right. As the figure shows






Run to the second step, as shown in the figure.



Run to the third step, as shown in the figure.



- The program will repeat the second and third steps.
- Notes:



- 1 Press and hold the three-position switch in manual mode, and the robot will suspend to move if you release the "Start" button.
- ② In manual mode, if you press and hold the "Start" button and release the three-position switch, the robot will give out the error alarm.

2.2 Auto mode

down the Mot button to enable, click on "Start" and run the program. Click the "Stop" button to pause the program.

3 Variable types and programming instructions

3.1 Introduction of variable types

3.1.1 Basic types

| Туре | Meaning | Value range | Corresponded |
|--------------|------------------|----------------|-------------------|
| | | | C++ type |
| BOOL | Boolean type | TRUE / | Bool |
| | | FALSE(1/0) | |
| INT | Integer | -2^15 ~ 2^15-1 | Short |
| UINT | Unsigned | 0 ~ 2^16-1 | Unsigned short |
| | integer | | |
| LINT | Long integer | -2^31 ~ 2^31-1 | Long int (the |
| | | | same with the int |
| | | | length) |
| ULINT | Unsigned long | 0 ~ 2^32-1 | Unsigned long int |
| | integer | | |
| FLOAT(REAL) | Single-precision | | Float |
| | floating point | | |
| DOUBLE(LREAL | Double-precisio | | Double |
|) | n floating point | | |
| STRING | String type | | String / char [] |



Usage of common types:

3.1.1.1 **BOOL**

For example, BOOL b1 := TRUE

3.1.1.2 **INT**

For example, INT int1 := -10

3.1.1.3 **UINT**

For example, UINT uint1 := 100

3.1.1.4 **LINT**

For example, LINT lint1 := -1000

3.1.1.5 **ULINT(DWORD)**

For example, ULINT ulint1 := 1000

3.1.2 Type of position data

The complex data types are defined in reference to the structure in the ROBOT data structure type that has already been defined. They will be provided to users as the options when the users creating variables, and user-defined data types are not allowed.

| Data type | Meaning | Corresponding internal type |
|-----------------|----------------------------------|-----------------------------|
| AXISPOS | Joint + Additional axis position | JointsPos + AuxPos |
| CARTPOS | Space + Additional axis position | CartPos + AuxPos |
| AXISPOSEXT | External joint position | Index of JointsAuxEXT |
| CARTPOSEXT | External space position | Index of CartAuxEXT |
| ROBOTAXISPOS | Robot joint position | JointsPos |
| ROBOTCARTPOS | Robot Cartesian position | CartPos |
| ROBOTAXISPOSEXT | External robot joint position | Index of JointsEXT |



| ROBOTCARTPOSEXT | External robot Cartesian position | Index of CartEXT |
|-----------------|---|------------------|
| AXISDIST | Relative joint + Additional axis position | RcDistance |
| CARTDIST | Relative Cartesian + Additional axis position | RcDistance |
| CARTPOSEE | Send Cartesian coordinate system data to PLC | |

CARTPOS, AXISPOSEXT, CARTPOSEXT, be AXISPOS, Such types can ROBOTAXISPOS, AUXAXISPOS, ROBOTCARTPOS, ROBOTAXISPOSEXT, AUXAXISPOSEXT and ROBOTCARTPOSEXT

3.1.2.1 **AXISPOS**

Joint + additional axis position, for which 6 joints + additional axes position at most, the type of each variable is DOUBLE, in degrees (°).

For example, AXISPOS ap1 := {13.22, 45, 21, 22.6, 40.7, 11, 2.4, 30.5, 40.11, 61.3, 11.4, 23.1}

3.1.2.2 **CARTPOS**

The spatial position under the Cartesian coordinate system, with additional axes up to 6. Variable is consisted of the X, Y, Z, A, B, C, Aux1 ~ 6 and Mode, wherein X ~ Aux6 is DOUBLE type, and Mode is UINT type.

For example, CARTPOS cp1 := {13.22, 45, 21, 22.6, 40.7, 11, 2.4, 30.5, 40.11, 61.3, 11.4, 23.13, 1}

3.1.2.3 AXISPOSEXT

External joint + additional axis position, in which only the UINT type value can be assigned. It represents an index of JointsAuxEXT [32].

For example, AXISPOSEXT ape1 := 5

3.1.2.4 CARTPOSEXT

External space+ additional axis position, in which only the UINT type value can



be assigned. It represents an index of CartAuxEXT [32].

For example, CARTPOSEXT cpe1 := 5

3.1.2.5 ROBOTAXISPOS

Robot joint position, up to six, and the type of each variable is DOUBLE, measured in degrees (°).

For example, ROBOTAXISPOS rap1 := {10.1, 10.1, 10.1, 10.1, 10.1, 10.1} For example, AUXAXISPOS raxp1 := {10.1, 10.1, 10.1, 10.1, 10.1, 10.1}

3.1.2.6 ROBOTCARTPOS

It is the spatial position under the Cartesian coordinate system. Variable is consisted of the X, Y, Z, A, B, C and Mode, wherein X~C is DOUBLE type, and Mode is UINT type.

For example, ROBOTCARTPOS rcp1 := {10.1, 10.1, 10.1, 10.1, 10.1, 10.1, 1}

3.1.2.7 ROBOTAXISPOSEXT

External joint position, in which only the UINT type value can be assigned, which indicates an index of JointsEXT [32].

For example, ROBOTAXISPOSEXT rape1 := 5

3.1.2.8 ROBOTCARTPOSEXT

External space position, in which only the UINT type value can be assigned, which indicates an index of CartEXT [32].

For example, ROBOTCARTPOSEXT rcpe1 := 5

3.1.2.9 **AXISDIST**

Relative joint+ additional axis position, for which, there're 6 joints+6 additional axes at most, and the type of each variable is DOUBLE, measured in degrees (°).

For example, AXISDIST ad1 := {10.1, 10.1}

3.1.2.10 **CARTDIST**

The spatial position under the Cartesian coordinate system, with additional axes up to 6. Variable is consisted of the X, Y, Z, A, B, C, Aux1 ~ 6 and Mode, wherein X ~ Aux6 is DOUBLE type, and Mode is UINT type.

For example, CARTDIST cd1 := {10.1, 10.1, 10.1, 10.1, 10.1, 10.1, 10.1, 10.1,



10.1, 10.1, 10.1, 10.1, 1}

3.1.3 Coordinate system and tool data types

| Data type | Meaning | Corresponded internal variables |
|--------------|----------------------|--------------------------------------|
| CARTREF | Reference coordinate | CartSys |
| | system | |
| CARTREFEXT | External reference | Index of m_RefExtern, along with the |
| | coordinate system | name of reference coordinate system |
| CARTREFVAR | External tracking | Index of m_RefVar, along with the |
| | coordinate system | name of reference coordinate system |
| CARTREFEXSYS | Additional axis | Index of m_RefExSys |
| | coordinate system | |
| TOOL | Tools | Tool |

3.1.3.1 **CARTREF**

The position of coordinate system against other reference coordinate systems, for which the variables consist of the X, Y, Z, A, B, C, as well as the name coordinate system that is used for reference, and X ~ C are DOUBLE type.

For example, CARTREF cr1 := {1.1, 1.2, 1.3, 1.4, 1.5, 1.6, crs0}

3.1.3.2 **CARTREFEXT**

External coordinate system, assigning with a value of UNIT type and indicating an index of m RefExtern [8]. There is also a value of STRING type that represents the reference coordinate system. The coordinate system used for reference is only the fixed coordinate system.

For example, CARTREFEXT cre1 := {5, crs0}

3.1.3.3 CARTREFVAR

External coordinate system, assigning with a value of UNIT type and indicating an index of m_RefVar [8]. There is also a value of STRING type that represents the reference coordinate system. The coordinate system used for reference is only the fixed coordinate system.

For example, CARTREFVAR crv1 := {5, crs0}



3.1.3.4 CARTREFSYSEXSYS

Additional axis coordinate system, assigning with a value of UNIT type and indicating an index of m_RefExSys [6].

For example, CARTREFEXSYS crex1 := 0

3.1.3.5 **TOOL**

The transformation matrix representing the tool. It consist of X, Y, Z, A, B and C, all of which are DOUBLE type.

For example, TOOL $t1 := \{1.1, 1.2, 1.3, 1.4, 1.5, 1.6\}$

3.1.4 Dynamic and oval characteristics

| Data type | Meaning | Corresponded |
|-----------|-------------------------------|--------------------|
| | | internal variables |
| DYNAMIC | Dynamic characteristics | DynamicPerc |
| OVLREL | OVLREL | Overlap |
| OVLABS | Absolute magnitude of ovality | Overlap |

3.1.4.1 **DYNAMIC**

It is composed by the position, rotation and joint velocity, acceleration, deceleration and jerk, totaling 12 quantities. It is based on the path type executed (for Cartesian or joint), and different amounts are used. 12 quantities are:

| PathVel | DOUBLE | Position velocity (mm/s) | |
|----------|--------|--------------------------|--|
| PathAcc | DOUBLE | Position acceleration | |
| | | (mm/s^2) | |
| PathDec | DOUBLE | Position deceleration | |
| | | (mm/s^2) | |
| PathJerk | DOUBLE | Position jerk (mm/s^3) | |
| OriVel | DOUBLE | Rotation speed (deg/s) | |
| OriAcc | DOUBLE | Rotation acceleration | |
| | | (deg/s^2) | |
| OriDec | DOUBLE | Rotation deceleration | |

グロアモビー A かみ Operation Instructions of SD Series 6-axis Robot

| | | (deg/s^2) |
|-----------|--------|-------------------------|
| OriJerk | DOUBLE | Rotation jerk (deg/s^3) |
| JointVel | DOUBLE | Joint velocity (%) |
| JointAcc | DOUBLE | Joint acceleration (%) |
| JointDed | DOUBLE | Joint deceleration (%) |
| JointJerk | DOUBLE | Joint jerk (%) |

For example, DYNAMIC dyn1 := {1000, 2000, 2000, 5000, 100, 200, 200, 500, 80,80,80,80}

3.1.4.2 **OVLREL**

It indicates the percentage of ovality, and is an amount of INT type, representing the percentum.

For example, OVERLAPREL ovl1 := 50

3.1.4.3 **OVLABS**

The variable type includes four members

| PosDist | DOUBLE | TCP position oval |
|-----------|--------|-------------------------|
| | | distance (mm) |
| oriDist | DOUBLE | TCP posture oval angle |
| | | (°) |
| linAxDist | DOUBLE | Oval distance of linear |
| | | axis (mm) |
| rotAxDist | DOUBLE | Oval angle of rotation |
| | | axis (°) |

For example, OVERLAPABS ovl2 := {1.1, 1.2, 1.3, 1.4}

3.1.4.4 **ORITYPE**

It indicates the posture on the path, belonging to enumerated types. The value is only three, as shown in below:

eVAR: // Make quaternion posture interpolation based on the posture information as demonstrated

// Keep the posture of starting position always eCONST:



eCIRCLE: // Keep the fixed posture with the round plane for circle interpolation

For example, ORITYPE oritype := eVAR

3.1.4.5 **RAMPTYPE**

Velocity planning types, consisting of three types: Trap, Shape and Ssine;

3.1.5 IO variable

It is composed of the digital input/output and analog input/output. Each type is equipped with two quantities: the port number and value.

| Data type | Meaning | Corresponded internal |
|-----------|----------------|-----------------------|
| | | type |
| DI | Digital input | DI |
| DO | Digital output | DO |
| Al | Analog input | AI[] |
| AO | Analog output | AO[] |

3.1.5.1 **DI**

Digital input, composing of the Port and Value. Port represents the DI port corresponded and Value indicates the value read over the port. Port is a figure (0-31), and Value is BOOL type.

For example, DI di1 := {0 ,TRUE }

3.1.5.2 **DO**

Digital output, composing of the Port and Value. Port represents the DO port corresponded and Value indicates the value read over the port. Port is a figure (0-31), and Value is BOOL type.

For example, DO do1 := {0, TRUE }

3.1.5.3 **AI**

Analog input, consisting of the Port and Value. Port represents the Al port corresponded and Value indicates the value read over the port. Port is a figure (0-31), and Value is INT type.

For example, Al ai1 := $\{0, 52\}$



3.1.5.4 **AO**

Analog output, consisting of the Port and Value. Port represents the AO port corresponded and Value indicates the value read over the port. Port is a figure (0-31), and Value is INT type.

For example, AO ao1 := $\{0, 11\}$

3.1.5.5 **BOOLEXT**

External (PLC) variable type. When it is required interacting with external bool variable, create and use the variable of such type as a parameter. This type of variable consists of the Port and Value, where Port is a figure (0-31), Value is bool type (the BOOL above). The defined data has the following format:

For example, BOOLEXT ext1 := {0, TRUE}

3.1.5.6 **DINTEXT**

External (PLC) variable type. When it is required interacting with external long integer variable, create and use the variable of such type as a parameter. This type of variable consists of the Port and Value, where Port is a figure (0-31), Value is DINT type (the LINT above). The defined data has the following format:

For example, DINTEXT ext1 := {0, 12}

3.1.5.7 **REALEXT**


External (PLC) variable type. When it is required interacting with external REAL variable, create and use the variable of such type as a parameter. This type of variable consists of the Port and Value, where Port is a figure (0-31), Value is REAL type (the FLOAT above). The defined data has the following format:

For example, REALEXT ext1 := {0, 1.1}

3.1.5.8 **DWORDEXT**

External (PLC) variable type. When it is required interacting with external DWORD variable, create and use the variable of such type as a parameter. This type of variable consists of the Port and Value, where Port is a figure (0-31), Value is DWORD type (the ULINT above). The defined data has the following format:

For example, DWORDEXT ext1 := $\{0, 222\}$.



3.2 Motion statement

Create and add in the previous line which you selected when editing the statement.

3.2.1 PTP

PTP: Point-to-point movement, for which the robot reaches the designated position with the fastest way, and the middle path is uncertain. As the figure shows






Figure 3-1 PTP schematic diagram

Select a new program, and open it. As the figure shows







After opening, EOF is terminator. As the figure shows



Choose "New", and display the statement classification. As shown in figure



Select the motion statements, and select PPT, and click OK. As the figure shows




 Click OK, the position, dynamic performance and ovality parameters are displayed, as the figure shows.

OK


Back

Cancel




 Select the position variable that has been established before at pos:Position (position), or you may choose to create a new one. As the figure below shows.






After selecting to create a new one, select the position type, and click OK. As the figure below shows.




- ➤ Where AXIS POS: joint + additional axis position; CART POS: Space + additional axis position.
- > See the position data type in variable introductions for the details of type of right position.



Following figure shows the situation when selecting the AXISPOS type and click OK.




Click Teaching after moving the robot to the position desired. As the figure below shows.




Click OK and display the position of current point. As the figure shows







Set the dynamic characteristic data dyn:Dynamic by selecting an existing parameter, or just creating a new parameter. As the figure shows



After choose to create a new parameter, only the DYNAMIC dynamic characteristics can be selected, or you may rename it. As the figure shows



Following figure shows the parameter data after clicking OK.






➤ Where the REAL PATHVEL position velocity (in MM/S, and 1000.00 is 1M/S) REAL ORIVEL rotational speed (in deg/s, 90.00 is 90deg/S)

REAL JOINVEL joint speed (depending on the percentage of motor speed, and 100.00 is 100%).

- See the dynamic/ovality type parameters in variable introductions for the details of type of right position.
- Set the ovality parameter ovl: Overlap by selecting an existing parameter, or just creating a new parameter. As the figure shows




The right data in figure above is as follows:

OVERLAPABS ovality absolute value (Generally not used)


OVERLAPREL ovality percentage (commonly used)

After clicking OK, and it will appear as the figure shows:





Click OK and there displays the written PTP point. As the figure shows





- > PTP usage:
- In case of only one parameter, the latter two parameters will use the default values PTP (param1); (common)

Have the first two user-defined parameters, and the third parameter uses the default value PTP (param1, optionparma2);

◆ The first and third use the user-defined parameters, but the second parameter uses the default value

PTP(param1, NULL, optionparma3);

◆ With three parameters using not the default values, but the user-specified variable

PTP(param1, optionparma2, optionparma3);

3.2.2 LIN

LIN: Linear motion, for which, the end of robot moves along a straight line to the specified position, and the posture and trajectory are determined. As the figure shows






Figure 3-2 LIN schematic diagram

Choose the motion statement, create a new Lin by referring to PTP. If you selecting CARTPOS type, and it shows in Figure as follows:






Dyn: Dynamic selects L dyn0, or may create a new one. As the figure shows




Ovl:Overlap select L orl0, or may create a new one. As the figure shows






Click OK, and create a new ori: ORITYPE (indicate the posture interpolation mode on the path). As the figure shows




You may rename by clicking the "New", as the figure shows.





After clicking OK, it appears as the figure shows



> ORITYPE indicates the posture on the path and enumerated types. The value is only three.






eVAR: // Make quaternion posture interpolation based on the posture information as demonstrated

eCONST: // Keep the posture of starting position always

eCIRCLE: // Keep the fixed posture with the round plane for circle interpolation

For example, ORITYPE oritype := eVAR

Click OK and there displays the Lin, as shown in the figure.



Usage of Lin:

The use rule of Lin statement is the same as what is described in PTP. Lin can have up to four parameters, where the first is the required, and others are optional.

3.2.3 Circ

Circ: Circular motion, for which the end of robot moves to the specified position along a circular arc, and the posture uncertain trajectory are determined. As the figure shows







Figure 3-3 Schematic diagram of circle

Choose the motion statement, and create a new Cric. As the figure shows



Parameters:

Cripos: Position// Auxiliary position on the arc

pos: Position // Destination position


dyn: Dynamic //Dynamic characteristics

ovl: Overlap//Ovality data

ori: ORITYPE //Posture parameters




Choose the parameter, or create a new one by referring to PTP. As the figure shows





Click OK and there displays the Circ. As the figure shows




Usage of Circ:

The instruction has two required parameters Circ (param1, parma2);


3.2.4 PTPRel

- PTPRel(dist,dyn,ovl) is a point-to-point relative motion instruction, where the moving distance is against the initial position of the robot (the position depends on the previous motion instruction).
- Choose the motion statement, and create a new PTPRo. As the figure shows





Click OK and select to create a new apd0. As the figure shows




The right side in figure above shows as follows:



AXISDIST: Relative joint+ additional axis position, for which, there're 6 joints+6 additional axes at most, and the type of each variable is DOUBLE, measured in degrees (°).

CARTDIST: The spatial position under the Cartesian coordinate system, with additional axes up to 6. Variable is consisted of the X, Y, Z, A, B, C, Aux1 ~ 6 and Mode, wherein X ~ Aux6 is DOUBLE type, and Mode is UINT type.


Click OK and there displays the PTPRel. As the figure shows




3.2.5 LinRel

- LinRel (dist, dyn, ovl, ori) is a relative linear motion instruction, where the moving distance is relative to the initial position of the robot (the position depends on the previous motion instruction).
- Choose the motion statement, create a new LinRel, and set parameters (refer to PTP). As shown in figure:





Click OK and there displays the LinRel. As the figure shows




3.2.6 WaitTime (timeMs)


The instruction pauses the robot timeMs time.

グロアモビー A かみ Operation Instructions of SD Series 6-axis Robot

Choose the motion statement, create a new WaitTime, while the new variable is uint 0, and also set the pause time. As shown in Figure (2000 indicate that the pause lasts for two seconds).



Click OK and there displays the WaitTime. As the figure shows







3.3 System parameters

3.3.1 Assignment statement

Select the system function and choose an assignment statement at right...: = ... (Assignment). As the figure shows




Click OK, select the left variable, and you can also create a new variable. As shown in the figure






After selecting to create a new one, there are basic types. As the figure shows




- See the position data type in variable introductions for the details of type of right position.
- Position type is shown in figure as:





- See the position data type in variable introductions for the details of type of right position.
- Tool types of coordinate system tool, as shown in figure



Introduction of types of common coordinate system tools at right:

CARTREF

The position of coordinate system against other reference coordinate systems, for which the variables consist of the X, Y, Z, A, B, C, as well as the name coordinate system that is used for reference, and X ~ C are DOUBLE type.

For example, CARTREF cr1 := {1.1, 1.2, 1.3, 1.4, 1.5, 1.6, crs0}

◆ CARTREFEXT

External coordinate system, assigning with a value of UNIT type and indicating an index of m_RefExtern [8]. There is also a value of STRING type that represents the reference coordinate system. The coordinate system used for reference is only the fixed coordinate system.

For example, CARTREFEXT cre1 := {5, crs0}



◆ CARTREFVAR

External coordinate system, assigning with a value of UNIT type and indicating an index of m RefVar [8]. There is also a value of STRING type that represents the reference coordinate system. The coordinate system used for reference is only the fixed coordinate system.


For example, CARTREFVAR crv1 := {5, crs0}

◆ TOOL

The transformation matrix representing the tool. It consist of X, Y, Z, A, B and C, all of which are DOUBLE type.

For example, TOOL $t1 := \{1.1, 1.2, 1.3, 1.4, 1.5, 1.6\}$

Type of DYNAMIC/ovality, as the figure shows.



Introduction of right types

DYNAMIC

It is composed by the position, rotation and joint velocity, acceleration, deceleration and jerk, totaling 12 quantities. It is based on the path type executed (for Cartesian or joint), and different amounts are used. 12 quantities are:



For example, DYNAMIC dyn1 := {1000, 2000, 2000, 5000, 100, 200, 200, 500, 80,80,80,80}

◆ OVLREL

It indicates the percentage of ovality, and is an amount of INT type, representing the percentum.

For example, OVERLAPREL ovl1 := 50

◆ OVLABS

The variable type includes four members (one less than the keba)

PosDist DOUBLE TCP position oval distance (mm)

oriDist DOUBLE TCP posture oval angle (°)

linAxDist DOUBLE Oval distance of linear axis (mm)

rotAxDist DOUBLE Oval angle of rotation axis (°)

For example, OVERLAPABS ovl2 := {1.1, 1.2, 1.3, 1.4}

◆ ORITYPE

It indicates the posture on the path and enumerated types. The value is only three.

eVAR: // Make quaternion posture interpolation based on the posture information as demonstrated

// Keep the posture of starting position always eCONST:

eCIRCLE: // Keep the fixed posture with the round plane for circle

interpolation


For example, ORITYPE oritype := eVAR

◆ RAMPTYPE


It include three types, the Trap, Sshape and Ssine;

If you choose the int in basic type, and it appears as the figure shows when clicking the operator.


グロアをこれの対策 Operation Instructions of SD Series 6-axis Robot




• Click the figures, and it shown as the figure shows.




Right variable settings, as the figure shows






Click OK, as shown in the figure




3.3.2 Comment statement

In the system function, upon selecting // ... comment statement, a comment is entered from the keyboard, such as enter wg. As the figure shows.






Click OK and there displays the comment statements. As the figure shows




In addition to the new statement, you may also click on "Comments" in the "Edit"



in the program, as shown in figure below




After making comment to the statement, it appears as figure below shows.






3.4 Stream statement

Select the stream data, and it appears as the figure shows.




3.4.1 While statement

When selecting the WHILE, and it appears as the figure shows.




Create the basic types. As the figure shows







- Type usage can refer to the assignment sentence in the system parameters.
- If you choose TRUE, it appears as the figure below shows





Write statement between "while" and "endwhile", and two motion statements will be written here.







- For example.
- > WHILE ()DO ... END WHILE

This instruction is used to repeat an instruction sequence when the conditions are satisfied. The usage is as follows:

```
WHILE(TURE)DO
PTP (SP007);
PTP (SP000, dyn0);
END WHILE
```

The program acts as follows: The robot makes reciprocating motion between SP007 and SP000.

Usage: The judgment condition behind WHILE need to return the BOOL type. Behind DO there is an instruction sequence, with no number restriction; END WHILE must be used at the end.

//WHILE standard format

WHILE (EXPRESS1)DO

STATEMENT;


END WHILE

Format Description: The three keywords required by the statement are "WHILE" "DO" "END WHILE". A parentheses is followed behind the WHILE, and the EXPRESS 1 in that parentheses is an expression, and the expression structure consists of three parts: Working equations1+ relation character + working equations 2, in which, the expression can be a single variable or an arithmetic formula, e.g., a, a + b * c and the like. Behind the parentheses is "DO", the content of next line is one or more lines of statements that can either be the assignment statements, or the motion instruction, or other statements. The last line uses "END_WHILE" string as the end of the entire statement.


3.4.2 If statement

Selecting IF, as the figure shows






Create variable UINT, as the figure shows





For example, create the bool 0 variable, and click OK. Enter a motion statement, as shown in Figure



The instruction control program flows into the conditional branch, and the example is given as follows:

IF(bool0=1)THEN

PTP(SP007);

END IF


The program acts as follows: When bool0 is 1, the robot moves to the SP007.

Usage: The determining conditions behind IF need to return the BOOL type, and there's no limitation for the THEN, ELSEIF, ELSE as well as number of their subsequent instructions; each IF instruction must use the keyword END_IF.


3.4.3 Loop statement

When selecting LOOP, the particulars is shown in figure






Create variable UINT, as the figure shows




Input the set value by keyboard. As the figure shows






Click OK. As the figure shows



For example, as the following procedures describe:





➤ LOOP ()DO ... END LOOP The instruction is used to execute the given number for the instruction sequence, and the usage is as follows:

```
LOOP(uint0)DO
PTP (SP004);
PTP (SP124);
END LOOP
```


The program acts as follows: Run the two statements in the LOOP for uint0 times.

Format Description: The number of cycles can only be replaced with the variables, but cannot directly enter the figures.


3.4.4 Lp statement

Select LP, as the figure shows






Create new variable INT type, as the figure shows






Set the value, as the figure shows




Click OK, as the figure shows






3.4.5 Goto and Ip statements

Select GOTO (conjunction with LP) and LP variables, click OK. As shown in the figure



As being explained by the following program:





➤ LP:int0: PTP(SP003); Circ(SP011,SP006); Lin(SP002); GOTO(int0);

The program acts as follows: Define the jump tag point int0, and moves to SP003 point in PTP, move to SP006 point in arc, move to SP002 point in straight, and then jump to the mode moving to SP003 in PTP. These can be done in cycles.


- LP Function Description: This instruction is used to define the jump tag point. Usage: Followed by the tag name (you can choose any one of the variable name).
- > GOTO Function Description: used to jump in different parts of the program. Usage: Followed by the jump tag (the tag must be consistent with that defined in the LP, or else the function fails).
- > LP:variable; GOTO (variable):

Format Description: LP is followed by the jump variable name as set by user (only a variable name is used as a jump identifier, but unconcern with the type of such variable), and there's variable name in the parentheses behind the GOTO, for which the variable must be defined after the LP (LP definition statement can be positioned in front or behind the GOTO).

3.5 I/O instruction


Choose I/O statement, as shown in the figure






3.5.1 DIRead instruction

Select DIRead, as shown in figure






Create the left operand specified bool type, as shown in figure




Click OK, and create the di: DI, as shown in the figure.






Click OK, and you can modify BOOL VALUE = TRUE / FALSE Click OK, you can modify BOOL VALUE = TRUE / FALSE. as the figure shows



Click OK, as shown in the figure.



Sentence format



BOOLVAR=DIRead(di);

> Parameters

di : DI //structure, including digital input signal port number and value (BOOL)

> Functional description

This instruction is used to read the digit input from the external data port, and the return value is bool type.


Writing example

Bool4:=DIRead(di0);


Program Description: Assign the data in digital quantity structure di0 to the variable bool4.


3.5.2 Diwait instruction

Select DIWAIT as shown in the diagram.




Select or create a new variable as shown in the diagram





Click OK as shown in the diagram





> Statement format

BOOLVAR=DIWAIT(di,val,time);

> Parameter

Di: DI

Val: BOOL

Time: UINT (ms) is optional

> Function description

This instruction is used to wait for the trigger signal within a specified waiting time and assign a value. The return value is boolean.


> Sample

Bool5=DIWAIT (di1,bool6,uint2);

The program demonstrates that within uint2, if val signal is received from the dil digital input terminal, bool5 is set to true.


3.5.3 Doset instruction

Select or create DoSet as shown in the diagram






Create do: DO, which has been specified as DO type as shown in the diagram.




Set val: BOOL parameter data FALSE/TRUE as shown in the diagram.



Click OK as shown in the diagram.





Statement format

DOSet(do,val);

Parameter

do: DO

val: BOOL

> Function description

This instruction is used to read the digital input from the external data port.

Sample


DOSet(do0,bool7);

Program function: assign the value of variable bool7 to do0.


3.5.4 BOOLEXTRead instruction

Create BOOLEXTRead as shown in the following diagram






Click OK as shown in the following diagram




It can select the defined variable or create a new variable as the variable. Select the new variable and click NEW as shown in the following diagram.






Modify its name and scope and click OK, and then turn to the interface shown in the following diagram.




Click the two parameter settings on the right side of parameter data and set the




parameter value. The parameter setting in the red box is finished after clicking OK.




Then set the variables in left operand as shown in the following diagram.



 Select the data type, change its name and scope, and then click OK as shown in the following diagram.



Change the parameter value, click OK and complete.





> Statement format

BOOLVAR= BOOLEXTRead(ext);

Parameter

ext: BOOLEXT //the structure, including the number and the value of the digital input signal port

> Function description

This instruction is used to read the specified variable in PLC. The return value is boolean.


Sample

bool0= BOOLEXTRead(boolext0);

The program demonstrates: assign the data in the external data structure boolext0 to the variable bool0.


3.5.5 BOOLEXTSet instruction

Create BOOLEXTSet as shown in the following diagram




Click OK and set New and the parameter data of ext and val variables.





Click OK and complete BOOLEXTSet statements shown in the following diagram.





> Statement format

BOOLEXTSet(ext, val);

Parameter

ext : BOOLEXT //the structure, including the number and the value of the digital input signal port

val: BOOL

> Function description

This instruction is used to set the specified variable in PLC.


> Sample

BOOLEXTSet(boolext1, TRUE);

The program function: assign the value of TRUE to the external data structure boolext1.

3.5.6 DINTEXTRead instruction


Create DINTEXTRead as shown in the following diagram




Click OK and complete it. The following three diagrams shows how to create the




variables and set their parameters.










Click OK and complete the statements shown in the following diagram.





> Statement format

DINTVAR= DINTEXTRead(ext);

Parameter

ext : BOOLEXT //the structure, including the number and the value of the digital input signal port

> Function description

This instruction is used to read the specified variable in PLC. The return value is DINT.


Sample

bool0=DINTEXTRead(boolext0);

The program function is to assign the data in boolext0 to the variable bool0.


3.5.7 DINTEXTSet instruction


Create DINTEXTSet as shown in the following diagram




Click OK and enter the following interface to create variables and parameter setting.










Click OK and complete the statements shown in the third line of the diagram.



Statement format

DINTEXTSet(ext, val);

Parameter

ext: BOOLEXT //the structure, including the number and the value of the digital input signal port

val: DINT(LINT)

> Function description

This instruction is used to set the value of the specified variable in PLC, in which val0 is DINT.

Sample


DINTEXTSet(dintext0, lint0);

The program function is to assign the data in lint0 to the variable dintext0.


3.5.8 REALEXTRead instruction

Create REALEXTRead as shown in the following diagram






Click OK and enter the following interface




Create the left side of variables and set the parameters.






Create the right side of variables and set the parameters.








Click OK and complete the statement as shown in the following diagram.





> Statement format

REALVAR= REALEXTRead(ext);

Parameter

ext: BOOLEXT //the structure, including the number and the value of the digital input signal port

> Function description

This instruction is used to read the specified variable in PLC. The return value is REAL.

Sample


real0= REALEXTRead(realext0);

The program function is to assign the data in realext0 to real0.


3.5.9 REALEXTSet instruction

Create REALEXTSet as shown in the following diagram






Click OK and enter the following interface







Create the first variable and set the parameter









Create the second variable and set the parameter







Click OK and complete the statement



Statement format

REALEXTSet(ext, val);



Parameter

//the structure, including the number and the value of the ext : BOOLEXT

digital input signal port

val: REAL

> Function description

This instruction is used to set the specified variable in PLC.


> Sample

REALEXTSet(realext1, real1);

The program function is to assign the value of real1 to realext1.


3.5.10 DWORDEXTRead instruction


Create DWORDEXTRead



Click OK. And firstly create the first variable and parameter setting.









Create the second variable and parameter setting


グロアモビー A かみ Operation Instructions of SD Series 6-axis Robot





Click OK and complete the creation of the statement.





> Statement format

DWORDVAR= DWORDEXTRead(ext);

Parameter

ext : BOOLEXT //the structure, including the number and the value of the digital input signal port

> Function description

This instruction is used to read the specified variable in PLC. The return value is DWORD.

Sample


ulint0= DWORDEXTRead(dwordext0);

The program function is to assign the data in dwordext0 to ulint0.


3.5.11 DWORDEXTSet instruction

Create DWORDEXTRead as shown in the following diagram.







Click OK and enter the following interface.






Create the first variable and set the parameter











Create the second variable and set the parameter





Click OK and complete the addition of the statement.



> Statement format

DWORDEXTSet(ext, val);

Parameter

ext: BOOLEXT //the structure, including the number and the value of the digital input signal port

val: DWORD (ULINT)

> Function description

This instruction is used to set the specified variable in PLC.

Sample

DWORDEXTSet(dwordext1, ulint1);


Assign the value of variable ulint to dwordext1.

3.6 Mathematical function instruction


3.6.1 SIN


Create a new instruction SIN as shown in the following diagram.






Create OK and create the first variable and set the parameter






Create the second variable and set the parameter



Click OK and complete the creation of the statement





Statement format

real:= SIN(deg);

Parameter

Parameter deg can be INT, FLOAT or DOUBLE (in angles)

> Function description

Assign the sin value of a real number to the other real number.


Sample

Real0:=SIN(int0);


Assign the sin value of the real number int0 to the other real number real0.

3.6.2 COS

Create a new instruction COS as shown in the following diagram.




Click OK and enter the next interface




Create the variable on the left side of variables and set the parameter

グロアモビー (A) Operation Instructions of SD Series 6-axis Robot




Create the variable in COS on the right side and set the parameter.





Click OK and complete the creation of the instruction





> Statement format

real:= COS(deg);

> Parameter

Parameter deg can be INT, FLOAT or DOUBLE (in angles)

> Function description

Assign the cosine value of a real number to the other real number.


> Sample

int0:=COS(real2);

Program function: assign the cosine value of the real number real2 to the real number int0.


3.6.3 TAN


Create the statement TAN as shown in the following diagram.



Click OK and then create and rename the right side of variable








Create the left side of variable and set the parameter






Click OK and complete the creation of the statement as shown in the following



diagram.



> Statement format

real:= TAN(deg);

> Parameter:

Parameter deg can be INT, FLOAT or DOUBLE (in angles)

> Function description

Assign the tan value of a real number to the other real number.

> Sample


Ireal3:=TAN(int4);

Program function: assign the tan value of the real number int4 to the real number Ireal3.


3.6.4 LN

Create the statement LN as shown in the following diagram.


グロアモビー A かみ Operation Instructions of SD Series 6-axis Robot




Click OK and enter the next interface



Create the left side of variable and set the parameter.




• Create the right side of variable and set the parameter.



Click OK and complete the creation of the statement





> Statement format

real:= LN(deg);

> Parameter

Parameter deg can be INT, FLOAT or DOUBLE (in angles).

> Function description

Assign the log value of a real number to the other real number.

Sample

real2:=LN(Ireal4);


Program demonstrates: assign the log value of the real number Ireal4 to the real number real2.

3.7 Bit operation instruments


3.7.1 SHL

Create the statement SHL as shown in the following diagram.

グロアモビー (A) Operation Instructions of SD Series 6-axis Robot




 Click OK and enter the variable creation and setting interface. Next create the left side of variable.












Next create the right side of variable and set the parameter.

















Click OK and complete the creation of the statement as shown in the following diagram.





> Statement format

int:=SHL (Expr, digit);

Parameter

Expr the value that will be moved digits the bits of the value that will be moved

> Function description

Move Expr digit bits to the left and then assign it to int.


Sample

int0:=SHL(int3,int4);


Program function: move int3 int4 bits to the left and then assign it to int0.

3.7.2 SHR

Create the statement SHR as shown in the following diagram.




Click OK and enter the following interface



Cancel

OK


Back



Next create the variable and set the parameter.


NULL: =SHL(NULL, NULL)

New





After setting all the three variables, click OK and complete the addition of the statement as shown in the following diagram.



Statement format

int:=SHR (Expr, digit);

Parameter

Expr the value that will be moved

digits the bits of the value that will be moved

> Function description

Move Expr digit bits to the right and then assign it to int.

Sample


int6:=SHR(int7,int8);

Program demonstrates: move int7 int8 bits to the right and then assign it to int6.


3.7.3 SetBit

Create SetBit as shown in the following diagram.





For the same principle, create the statement, create and set the variable. After completion click OK to complete the addition of the statement.



Statement format



int:=SetBit (val,bitNr);

Parameter

the value that will be set val

bitNr the bit that needs to be set

> Function description

Set the value of bitNr bit in val to 1 and then assign it to int.

> Sample

int6:=SetBit(int6,int7);

Program function: set the int7th position of int6 to 1 and then assign it to int6.

3.8 Operators

3.8.1 Mathematical operators

- + add operation
- minus operation
- * multiply operation

/ division operation

% complementation

Usage: both sides can be digits or the basic data type variable

3.8.2 Relational operators

- < less than
- <= less than or equal to
- > more than
- >= more than or equal to
- = equal to
- != unequal to

Usage: both sides can be digits or the basic data type variable

3.8.3 Separators and other symbols

: colon

Usage: used as the assignment symbols

comma



Usage: used between parameters.

() braces (be applicable for the parameter, initialization list and an arithmetic expression)

Usage: used after the instruction that needs parameters.

Appendix: Error codes and processing methods

| ID | Description in English | Description in | Reason | Processing method |
|----|------------------------|----------------|-------------|------------------------------|
| | | Chinese | | |
| 0 | | Servo error | Servo error | It can see the error code |
| | | | | and processing of the |
| | | | | servo. |
| | | | | Suggested processing |
| | | | | method: |
| | | | | 1) Clear the error to |
| | | | | continue to operate; if |
| | | | | the error is still reported, |
| | | | | this sort of error needs |
| | | | | to be corrected |
| | | | | manually. |
| | | | | 2) If it is unable to clear |
| | | | | the error, it needs to |
| | | | | check whether the wire |
| | | | | is virtually connected, |
| | | | | whether the control |
| | | | | mode of the servo is |
| | | | | right, and whether the |
| | | | | motor or servo is |
| | | | | damaged. |



| 100 | Robot is not initiated | Robot is not | The initialization | The initialization block |
|-----|------------------------|--------------|--------------------|----------------------------|
| 100 | Robot is not initiated | | | |
| | | initiated | block isn't called | needs to be added in |
| | | | in PLC program. | PLC program. |
| | | | | The new software and |
| | | | | engineering shall be |
| | | | | provided by the System |
| | | | | Department. |
| 101 | Parameter is illegal | Parameter is | - | Submit a BUG |
| | | illegal | | |
| 102 | Pointer is Zero | | - | Submit a BUG |
| 103 | Robot is not ready to | Robot is not | A certain servo | When checking the |
| | switch on | ready to | axis is not ready. | situation of a servo, if a |
| | | switch on | | servo is reporting the |
| | | | | error, manual operation |
| | | | | shall be carried out to |
| | | | | solve the servo error. |
| 150 | Error change operation | Cannot | The operation | If it is the human that |
| | mode when robot moving | change the | mode is changed | turns the key when robot |
| | | operation | when the robot is | is running, it is the |
| | | mode when | moving. | normal error report. It |
| | | the robot is | | shall avoid to directly |
| | | running | | switch the locomotion |
| | | | | pattern when the robot is |
| | | | | moving. It can suspend |
| | | | | motion firstly before |
| | | | | switching. |



| 151 | Robot is disabled when it | Robot is | The enable is cut | It cannot operate the |
|-----|---------------------------|----------------|----------------------|------------------------------|
| | is moving | disabled when | off when the | enable when the robot is |
| | | it is running | robot is running. | running, therefore, the |
| | | | | error happens. It needs |
| | | | | check whether the servo |
| | | | | reports the error or not. |
| | | | | If it isn't the error caused |
| | | | | by the manual operation, |
| | | | | it is likely that the wire |
| | | | | which is set up to |
| | | | | operate the robot to a |
| | | | | certain place breaks off |
| | | | | or is interrupted in a |
| | | | | certain place. It needs to |
| | | | | check the line and |
| | | | | consider to add the line |
| | | | | shield. |
| 200 | No base joint | No joint axis | 1) The joint axis | 1) Check whether the |
| | | | isn't equipped; 2) | configuration files is |
| | | | the configuration | damaged or not; 2) the |
| | | | file isn't contacted | receiver function shall |
| | | | with. | be called in the correct |
| | | | | order in PLC program. |
| 201 | Joint number is wrong | The number of | When receiving | Same as 200 |
| | | joint is wrong | the type of the | |
| | | | joint, if the input | |
| | | | joint name is an | |
| | | | Aux joint and it | |
| | | | doesn't exist, this | |





| | | | error will be | |
|-----|----------------------------|----------------|---------------------|--------------|
| | | | reported. | |
| | | | | |
| 202 | Aux joint number is zero | The number of | When the number | Same as 200 |
| | | aux joints is | of aux joints is | |
| | | zero | zero and it isn't a | |
| | | | guide rail, the | |
| | | | error is reported. | |
| 203 | Aux joint number is out of | The number of | Same as 200 | Same as 200 |
| | three | aux joints is | | |
| | | more than | | |
| | | three in a aux | | |
| | | joint system. | | |
| 250 | Error Create Queue | Queue | - | Submit a BUG |
| | | creation is | | |
| | | failed | | |
| 251 | Program is NULL | Program is | - | Submit a BUG |
| | | NULL | | |
| 252 | No enough Memory | No enough | - | Submit a BUG |
| | | memory | | |
| 280 | Segment Queue is NULL | Path queue | - | Submit a BUG |
| | | pointer is | | |
| | | NULL | | |
| 281 | Segment Queue is full | Path queue is | - | Submit a BUG |
| | | full | | |
| 282 | Segment Queue is empty | Path queue is | - | Submit a BUG |
| | | empty | | |
| 283 | Segment Queue is out of | Path queue is | - | Submit a BUG |
| | range | out of range | | |



グロアをこれの対策 Operation Instructions of SD Series 6-axis Robot

| 300 | MovePoint Queue is | MovePoint | - | Submit a BUG |
|-----|--------------------------|-----------------|---|--------------|
| | wrong | queue is | | |
| | | wrong | | |
| 301 | MovePoint Queue is | MovePoint | - | Submit a BUG |
| | NULL | queue is | | |
| | | NULL | | |
| 302 | MovePoint Queue is full | MovePoint | - | Submit a BUG |
| | | Queue is full | | |
| 303 | MovePoint Queue is | MovePoint | - | Submit a BUG |
| | empty | queue is | | |
| | | empty | | |
| 304 | MovePoint Queue is clear | MovePoint | - | Submit a BUG |
| | | Queue is clear | | |
| 305 | MovePoint Queue is out | MovePoint | - | Submit a BUG |
| | of range | Queue is out | | |
| | | of range | | |
| 320 | Queue is full | Queue is full | - | Submit a BUG |
| 321 | Queue is empty | Queue is | - | Submit a BUG |
| | | empty | | |
| 322 | Queue is out of range | Queue is out | - | Submit a BUG |
| | | of range | | |
| 323 | Queue item is already | Queue item | - | Submit a BUG |
| | exist | already exists | | |
| 324 | Queue item is not exist | Queue item | - | Submit a BUG |
| | | does not exist | | |
| 340 | Stack is full | Stack is full | - | Submit a BUG |
| 341 | Stack is empty | Stack is empty | - | Submit a BUG |
| 342 | Path end flag | Path end flag | - | Submit a BUG |
| 343 | Stack is out of range | Stack is out of | - | Submit a BUG |
| | • | | | |






| | | range | | |
|-----|---------------------------|---------------|---------------------|---------------------------|
| 360 | Too many reference | Too many | The used | Decrease the number of |
| | system in a program | reference | reference | the reference coordinate |
| | | coordinate | coordinate | system. |
| | | systems in a | systems are more | |
| | | program | than 50 in a | |
| | | | program. | |
| | | | | |
| 500 | ErrNotAutomaticExternal | Not in the | When calling | The robot shall be |
| | | external | function, the | switched to the external |
| | | automatic | robot isn't in the | automatic mode. |
| | | mode | external | |
| | | | automatic mode. | |
| 501 | ErrFBBusy | "Busy" | PLC Interface | PLC program is |
| | | program block | function is | suggested to be |
| | | | offending. | simplified. |
| 502 | ErrNoControlAuthority | No control | When PLC | The authorized function |
| | | authority | Interface function | shall be called in PLC |
| | | | is called, there is | program. |
| | | | no control | |
| | | | authority. | |
| | | | | |
| 550 | Illegal correct dimension | Illegal | Wrong searching | Submit a BUG |
| | | dimension of | bits | |
| | | searching | | |
| | | correction | | |
| 551 | Illegal CD when correct | Illegal | When correcting, | In accordance with the |
| | | searching | it uses the illegal | right locating operation, |
| | | parameter | searching data. | using the searching |



| | | | | function by firstly |
|-----|-------------------------|----------------|--------------------|----------------------------|
| | | | | searching and then |
| | | | | correcting. |
| 552 | the CD Refsyses are not | The CD | Using the | It can be corrected by |
| | same | Refsyses are | searching points | using the searching |
| | | different in | which are in the | points in the same |
| | | searching | different | coordinate system. |
| | | correction | reference | |
| | | program | coordinate | |
| | | | systems. | |
| 553 | Laser searching while | Touch sensor | The laser | Determine whether to |
| | touch device | is selected as | searching | use the laser searching |
| | | the laser | function is called | or the touch searching. If |
| | | searching | when the touch | the touch searching is |
| | | sensor. | searching is | used, the touch |
| | | | equipped. | searching is selected in |
| | | | | the searching statement. |
| | | | | If the laser searching, |
| | | | | the laser sensor needs |
| | | | | to be equipped. |
| 554 | Wire contacting before | The wire | The wire contacts | 1. Adjust the torch |
| | searching | contacts with | with the | position; 2. Adjust the |
| | | the workpiece | workpiece before | workpiece position. |
| | | before | searching. | |
| | | searching | | |
| 555 | No workpiece is found | No workpiece | Workpiece is out | 1. Increase the |
| | during searching | is found | of the searching | searching scope; 2. |
| | | during | range. | Adjust the workpiece |
| | | searching | | position |





| | T | 1 | 1 | T |
|-----|-----------------------------|----------------|-------------------|-------------------------------|
| 556 | Position of workpiece out | Position of | Worrpiece is out | 1. Increase the deviation |
| | of search distance | the workpiece | of the acceptable | tolerance; 2. Adjust the |
| | | is out of | deviation range. | workpiece position |
| | | searching | | |
| | | distance | | |
| 557 | Illegal search process | | - | Submit a BUG |
| 558 | Arc on out of time | Arc on out of | Arcing time is | 1. Check whether the |
| | | time | more than 10s. | welding machine is |
| | | | | normal or not. |
| | | | | 2. Check whether the |
| | | | | communication between |
| | | | | the welding machine |
| | | | | and the robot is normal |
| | | | | or not. |
| | | | | 3. Check whether the |
| | | | | welding torch is normal |
| | | | | or not. |
| 559 | Illegal arc on process | | - | Submit a BUG |
| 560 | Arc off out of time | Arc off out of | Arc failure is | Check whether the |
| | | time | more than 10s | communication between |
| | | | | the welding machine |
| | | | | and the robot is normal |
| | | | | or not. |
| 561 | Illegal arc off process | | - | Submit a BUG |
| 562 | Illegal arc settings except | | - | Submit a BUG |
| | set,mode,job | | | |
| 563 | Error RobotType was | Non-six-joint | Same as the | Check the type of the |
| | Used,not General Robot | serial robot. | Description | robot equipped by the |
| | | The joint | | configuration files. If it is |
| | | | | |



| | | swing is only | | the non-six-joint serial |
|-----|---------------------------|------------------|----------------------|----------------------------|
| | | used in the | | robot, it needs to change |
| | | general | | the arcing means. |
| | | machine. | | |
| 564 | CurrentTool not | Current tool is | Same as the | 1. Change the tool |
| | appropriate for | not | Description | |
| | WristWeave | appropriate for | | 2. Change the welding |
| | | Wrist Weave | | pose. |
| 565 | Do not support double | Do not | - | Submit a BUG |
| | search yet | support | | |
| | | double | | |
| | | searching yet | | |
| 100 | Joint velocity limit is | Joint velocity | 1) The joint axis | 1) Check whether the |
| 0 | NULL | limit | isn't equipped; 2) | configuration files is |
| | | parameter is | the configuration | damaged or not; 2) the |
| | | NULL | file isn't contacted | receiver function shall |
| | | | with. | be called in the correct |
| | | | | order in PLC program. |
| 100 | Joint limit parameters is | Joint limit | 1) The joint axis | 1) Check whether the |
| 1 | NULL | parameters is | isn't equipped; 2) | configuration files is |
| | | NULL | the configuration | damaged or not; 2) the |
| | | | file isn't contacted | receiver function shall |
| | | | with. | be called in the correct |
| | | | | order in PLC program. |
| 100 | Joint1 is singular | Joint1 is | Same as the | Change the mode of |
| 2 | | singular | Description | motion to PTP or fine |
| | | | | tune the position point. |
| 100 | Joint1 is out of space | Joint1 is out of | 1. The joint1 is | Check whether it is out |
| 3 | | space | out of space; | of space or not. If it is, |



| | | 1 | | 1 |
|-----|------------------------|------------------|--------------------|-----------------------------|
| | | | 2. Given | the joint shall be jogged |
| | | | cartesian position | back to the space. If the |
| | | | and pattern | error information is |
| | | | cannot get the | caused by the |
| | | | joint solution. | initialization of the path, |
| | | | | it shall determine |
| | | | | whether the robot can |
| | | | | arrive at the given |
| | | | | cartesian position and |
| | | | | pattern or not. |
| 100 | Joint2 is out of limit | Joint2 is out of | Same as 1003 | Same as 1003 |
| 4 | | limit | | |
| 100 | Joint3 is out of limit | Joint3 is out of | Same as 1003 | Same as 1003 |
| 5 | | limit | | |
| 100 | Joint4 is out of limit | Joint4 is out of | Same as 1003 | Check whether it is out |
| 6 | | limit | | of space or not. If it is, |
| | | | | the joint shall be jogged |
| | | | | back to the space. If it |
| | | | | isn't, it shall determine |
| | | | | whether it is located |
| | | | | near the singular |
| | | | | location or not. If it is |
| | | | | near the singular |
| | | | | location, fine tune the |
| | | | | target point of the robot. |
| | | | | If it is neither out of |
| | | | | space nor singular, then |
| | | | | reduce the operating |
| | | | | speed. If it continues to |
| | | | | |

グロアモビー (A) Operation Instructions of SD Series 6-axis Robot

| | | | | report that the axis is out of space, it is the software defects. |
|-----|------------------------|------------------|--------------|---|
| 100 | Joint5 is out of limit | Joint5 is out of | Same as 1003 | Check whether it is out |
| 7 | | limit | | of space or not. If it is, |
| | | | | the joint shall be jogged |
| | | | | back to the space. If it |
| | | | | isn't, it shall determine |
| | | | | whether it is located |
| | | | | near the singular |
| | | | | location or not. If it is |
| | | | | near the singular |
| | | | | location, fine tune the |
| | | | | target point of the robot. |
| | | | | If it is neither out of |
| | | | | space nor singular, then |
| | | | | reduce the operating |
| | | | | speed. If it continues to |
| | | | | report that the axis is out |
| | | | | of space, it is the |
| | | | | software defects. |
| 100 | Joint6 is out of limit | Joint6 is out of | Same as 1003 | Check whether it is out |
| 8 | | limit | | of space or not. If it is, |
| | | | | the joint shall be jogged |
| | | | | back to the space. If it |
| | | | | isn't, it shall determine |



| whether it is local near the singular location or not. If near the singular location, fine tun target point of the | it is e the |
|--|----------------|
| location or not. If near the singular location, fine tun | it is e the |
| near the singular location, fine tun | e the |
| location, fine tun | e the |
| | |
| target point of the | |
| langer penne of an | e robot. |
| If it is neither out | of |
| space nor singul | ar, then |
| reduce the operation | ating |
| speed. If it contin | nues to |
| report that the ax | is is out |
| of space, it is the | ; |
| software defects | |
| 100 Joint3 does not have Real Joint3 does Same as Same as 1002 | |
| 9 solve not have Description | |
| solution | |
| 101 Joint2 does not have Real Joint2 does Same as Same as 1002 | |
| 0 solve not have Description | |
| solution | |
| 101 Joint5 is singular Joint5 is Same as Same as 1002 | |
| 1 singular Description | |
| 101 Joint5 is singular and Joint5 is Same as Same as 1002 | |
| 2 joint6 is out of limit singular and Description | |
| joint6 is out of | |
| limit | |
| 101 AuxJoint1 is out of limit Aux joint1 is Aux joint1 is out When the aux jo | nt1 is |
| 3 out of limit of limit or speed. out of limit or speed. | ed, it |
| shall determine v | vhether |
| the aux joint 1 is | |



| | | | | reported to be out of limit |
|-----|---------------------------|------------------|--------------|--------------------------------|
| | | | | or not. If it is, jog it back. |
| | | | | If it isn't, reduce the |
| | | | | speed of the path. |
| 101 | AuxJoint2 is out of limit | AuxJoint2 is | Same as 1013 | Same as 1013 |
| 4 | | out of limit. | | |
| 101 | AuxJoint3 is out of limit | AuxJoint3 is | Same as 1013 | Same as 1013 |
| 5 | | out of limit. | | |
| 101 | AuxJoint4 is out of limit | AuxJoint4 is | Same as 1013 | Same as 1013 |
| 6 | | out of limit. | | |
| 101 | AuxJoint5 is out of limit | AuxJoint5 is | Same as 1013 | Same as 1013 |
| 7 | | out of limit. | | |
| 101 | AuxJoint6 is out of limit | AuxJoint6 is | Same as 1013 | Same as 1013 |
| 8 | | out of limit. | | |
| 101 | PalletizerRobotOri is err | Posture error | The wrong | When the user sets the |
| 9 | | of Cartesian | posture of | Cartpos pose, please |
| | | points in | Cartpos | input the correct posture |
| | | four-joint | | or demonstrate the |
| | | palletizer | | cartpos point by jogging. |
| | | robot | | |
| 102 | Joint1 is out of speed | Joint1 is out of | Same as | Reduce the speed or the |
| 0 | | speed | Description | percentage of the |
| | | | | speed. If the error still |
| | | | | exists, submit a bug. |
| 102 | Joint2 is out of speed | Joint2 is out of | Same as | Same as 1020 |
| 1 | | speed | Description | |
| 102 | Joint3 is out of speed | Joint3 is out of | Same as | Same as 1020 |
| 2 | | speed | Description | |
| 102 | Joint4 is out of speed | Joint4 is out of | Same as | Same as 1020 |





| 3 | | speed | Description | |
|-----|--------------------------|------------------|-------------|---------------|
| 102 | Joint5 is out of speed | Joint5 is out of | Same as | Same as 1020 |
| 4 | | speed | Description | |
| 102 | Joint6 is out of speed | Joint6 is out of | Same as | Same as 1020 |
| 5 | | speed | Description | |
| 102 | Joint5 is near singular | Joint5 is | Same as | Same as 1020 |
| 6 | and joint 4 out of speed | almost | Description | |
| | | singular and | | |
| | | joint 4 out of | | |
| | | speed | | |
| 102 | Joint5 is near singular | Joint5 is | Same as | Same as 1020 |
| 7 | and joint 6 out of speed | almost | Description | |
| | | singular and | | |
| | | joint 6 out of | | |
| | | speed | | |
| 150 | Error PTP initial | PTP path | - | Submit a BUG |
| 0 | | initialization | | |
| | | error | | |
| 150 | Error PTPREL initial | PTPREL path | - | Submit a BUG |
| 1 | | initialization | | |
| | | error | | |
| 150 | Error Line initial | Linear path | - | Submit a BUG |
| 2 | | initialization | | |
| | | error | | |
| 150 | Error LineREL initial | Relative linear | - | \Submit a BUG |
| 3 | | path | | |
| | | initialization | | |
| | | error | | |
| 150 | Error Circle initial | Circle path | - | Submit a BUG |





| 4 | | initialization | | |
|-----|---------------------------|----------------|----------------------|--------------------------|
| | | error | | |
| 150 | Error CircleAngle initial | CircleAngle | - | Submit a BUG |
| 5 | | path | | |
| | | initialization | | |
| | | error | | |
| 150 | Error Spline initial | Spline path | - | Submit a BUG |
| 6 | | initialization | | |
| | | error | | |
| 200 | DH parameter is NULL | DH parameter | 1) The joint axis | 1) Check whether the |
| 0 | | pointer is | isn't equipped; 2) | configuration files is |
| | | NULL | the configuration | damaged or not; 2) the |
| | | | file isn't contacted | receiver function shall |
| | | | with. | be called in the correct |
| | | | | order in PLC program. |
| 200 | DH parameter is NULL in | DH parameter | 1) The joint axis | 1) Check whether the |
| 1 | Inv_kinematics | pointer is | isn't equipped; 2) | configuration files is |
| | | NULL in | the configuration | damaged or not; 2) the |
| | | inv_kinematic | file isn't contacted | receiver function shall |
| | | s | with. | be called in the correct |
| | | | | order in PLC program. |
| 200 | Error happened in getting | Error happens | 1) The joint axis | 1) Check whether the |
| 2 | DH Parameters | in getting DH | isn't equipped; 2) | configuration files is |
| | | Parameters | the configuration | damaged or not; 2) the |
| | | | file isn't contacted | receiver function shall |
| | | | with. | be called in the correct |
| | | | | order in PLC program. |
| 210 | Reference type is wrong | The type of | - | Submit a BUG |
| 0 | | reference | | |

グロアモビー (A) Operation Instructions of SD Series 6-axis Robot

| | | coordinate | | |
|-----|----------------------------|-----------------|----------------------|--------------------------|
| | | system is | | |
| | | wrong | | |
| 210 | Position type is wrong | Position type | - | Submit a BUG |
| 1 | | is wrong | | |
| 210 | Axis type is wrong | Axis type is | - | Submit a BUG |
| 2 | | wrong. Not the | | |
| | | liner axis or | | |
| | | the rotation | | |
| | | axis | | |
| 210 | Ramp type is wrong | Velocity | - | Submit a BUG |
| 3 | | planning type | | |
| | | is wrong | | |
| 210 | Segment type is wrong | Path type is | - | Submit a BUG |
| 4 | | wrong | | |
| 220 | override parameter is | Speed control | - | Submit a BUG |
| 0 | wrong | parameter is | | |
| | | wrong | | |
| 220 | target length is less than | The length of | - | Submit a BUG |
| 1 | zero | the path target | | |
| | | is less than | | |
| | | zero | | |
| 220 | Cycle time less than zero | Interpolation | 1) The joint axis | 1) Check whether the |
| 2 | | cycle is less | isn't equipped; 2) | configuration files is |
| | | than zero | the configuration | damaged or not; 2) the |
| | | | file isn't contacted | receiver function shall |
| | | | with. | be called in the correct |
| | | | | order in PLC program. |
| 220 | Blend condition is not one | Overlap sign | - | Submit a BUG |
| | | | | |



グロアをこれの対策 Operation Instructions of SD Series 6-axis Robot

| 3 | or zero | is wrong, | | |
|-----|-----------------------------|-----------------|---|--------------|
| | | which is not | | |
| | | one or zero | | |
| 220 | Overlap parameter is not | Overlap | - | Submit a BUG |
| 4 | appropriate | parameter is | | |
| | | not | | |
| | | appropriate | | |
| 220 | Orientation interpolation | Orientation | - | Submit a BUG |
| 5 | type is wrong | interpolation | | |
| | | type is wrong | | |
| 220 | Velocity is not appropriate | Velocity | - | Submit a BUG |
| 6 | | parameter is | | |
| | | less than zero | | |
| 220 | Acceleration is not | Acceleration | - | Submit a BUG |
| 7 | appropriate | parameter is | | |
| | | not | | |
| | | appropriate | | |
| 220 | Deceleration is not | Deceleration | - | Submit a BUG |
| 8 | appropriate | parameter is | | |
| | | not | | |
| | | appropriate | | |
| 220 | Jerk is not appropriate | Jerk is not | - | Submit a BUG |
| 9 | | appropriate | | |
| 230 | Position is NULL | Position | - | Submit a BUG |
| 0 | | pointer is | | |
| | | NULL | | |
| 230 | Segment is NULL | Path pointer is | - | Submit a BUG |
| 1 | | NULL | | |
| 230 | RobotBase is NULL | Pointer of the | - | Submit a BUG |



| 2 | | robot base | | |
|-----|---------------------------|------------------|---|--------------|
| | | coordinate | | |
| | | system is | | |
| | | NULL. | | |
| 250 | THe parameter x of | The | - | Submit a BUG |
| 0 | sqrt(x) less than zero | parameter x of | | |
| | | sqrt(x) is less | | |
| | | than zero | | |
| 250 | Rcpos transfer to Posfull | Structure error | - | Submit a BUG |
| 1 | error | by the transfer | | |
| | | from Rcpos to | | |
| | | Posful | | |
| 250 | Error in KineForward | Forward | - | Submit a BUG |
| 2 | function | kinematics | | |
| | | error | | |
| 250 | Error get robot mode | Robot mode | - | Submit a BUG |
| 3 | | error | | |
| 250 | Error Velocity Profile | Velocity profile | | Submit a BUG |
| 4 | | error | | |
| 300 | JogPath is NULL | Jogging | - | Submit a BUG |
| 0 | | structure | | |
| | | pointer is | | |
| | | NULL | | |
| 300 | JogSegment is NULL | Jogging path | - | Submit a BUG |
| 1 | | pointer is | | |
| | | NULL | | |
| 320 | Jog Reference system is | Jogging | - | Submit a BUG |
| 0 | wrong | reference | | |
| | | coordinate | | |



| | | system is | | |
|-----|---------------------------|-----------------|---|--------------|
| | | wrong | | |
| 320 | MoveType Parameter is | Jogging axle | - | Submit a BUG |
| 1 | wrong | type is wrong | | |
| 320 | JogMode Parameter is | Jogging mode | | Submit a BUG |
| 2 | wrong | is wrong | | |
| 320 | Error in T_velocity | Jogging | - | Submit a BUG |
| 3 | | T_velocity | | |
| | | planning error | | |
| 320 | Error in Absolute Jogging | Linear jogging | - | Submit a BUG |
| 4 | initial | path | | |
| | | initialization | | |
| | | error at | | |
| | | absolute | | |
| | | positions | | |
| 320 | Get JointPos error in | Joint position | - | Submit a BUG |
| 5 | increment Jogging | error after | | |
| | | getting the | | |
| | | joint increment | | |
| | | jogging | | |
| 320 | Get CartPos error in | CartPos error | - | Submit a BUG |
| 6 | increment Jogging | after getting | | |
| | | Cartesian | | |
| | | increment | | |
| | | jogging | | |
| 320 | Get JointPos error in | JointPos error | - | Submit a BUG |
| 7 | absolute (PTP) Jogging | after getting | | |
| | | PTP jogging | | |
| | | at absolute | | |





| | | positions | | |
|-----|----------------------------|------------------|---|--------------------------|
| 320 | Get cartPos error in | CartPos error | - | Submit a BUG |
| 8 | absolute (Line) Jogging | after getting | | |
| | | linear jogging | | |
| | | at absolute | | |
| | | positions | | |
| 320 | SubDyn is NULL | Velocity | - | Submit a BUG |
| 9 | | structure | | |
| | | pointer is | | |
| | | NULL | | |
| | | | | |
| 321 | Direction type is wrong | Jogging | - | Submit a BUG |
| 0 | | direction is | | |
| | | wrong | | |
| 321 | Jogging Unit is too big or | Jogging Unit | - | Submit a BUG |
| 1 | to small | is too big or to | | |
| | | small | | |
| 321 | Path velocity greater than | Path velocity | - | Submit a BUG |
| 2 | 250mm/s | is greater than | | |
| | | 250mm/s | | |
| 330 | Rotation to RPY singular | RPY from the | - | Submit a BUG |
| 0 | | pose matrix to | | |
| | | the fixed angle | | |
| | | is singular | | |
| 340 | Not find Program variable | Not find or | | Check whether the |
| 0 | or var illegal | illegal to use | | variable exists or not |
| | | variable | | from the variable |
| | | | | interface; check whether |
| | | | | the statement allows to |



| | | | I | 1 |
|-----|---------------------------|------------------|---------------------|-----------------------------|
| | | | | insert the variable. If the |
| | | | | variable doesn't exist |
| | | | | really, create a new |
| | | | | variable with the same |
| | | | | name. |
| 340 | Program variable type not | Variable type | Variable type is | Check srd file and |
| 1 | exist | is wrong | wrong | manually delete the |
| | | | | variable. |
| 340 | Program variable Name | Variable name | Variable name is | Check srd file and revise |
| 2 | empty | is empty | empty | based on the format |
| | | | | definition. |
| 340 | Program bool variable | Boolean | Boolean variable | Check srd file and revise |
| 3 | value err | variable is | is wrong | based on the format |
| | | wrong | | definition. |
| 340 | Program numerical | Format error | Format error of | Check srd file and revise |
| 4 | variable value err | of integral and | integral and | based on the format |
| | | floating-point | floating-point | definition. |
| | | data values | data values | |
| 340 | Program string variable | Format error | Format error of | Check srd file and revise |
| 5 | value err | of string | string variable | based on the format |
| | | variable | values | definition. |
| | | values | | |
| 340 | "{"or"}" err | Lack of brace | Lack of brace | Check srd file and revise |
| 6 | | | | based on the format |
| | | | | definition. |
| 340 | Program ORITYPE | ORITYPE | ORITYPE | Check srd file and revise |
| 7 | variable value err | variable | variable definition | based on the format |
| | | definition error | error | definition. |
| 340 | Program RAMPTYPE | RAMPTYPE | RAMPTYPE | Check srd file and revise |
| | | | | |





| 8 | variable value err | variable | variable definition | based on the format |
|-----|----------------------------|------------------|---------------------|---------------------------|
| | | definition error | error | definition. |
| 340 | Program Define Var | Variable | Variable | Check srd file and delete |
| 9 | Twice | redefinition | redefinition | the unnecessary |
| | | | | variables |
| 341 | Program Ref Var Not Find | Variable | Variable | Check srd file and revise |
| 0 | | definition error | definition error in | based on the format |
| | | in the | the coordinate | definition. |
| | | coordinate | system | |
| | | system | | |
| 341 | Not Find Project | Lack of project | All project files | Create a new project file |
| 1 | File,Created in Controller | files | are deleted. | based on the definition. |
| 341 | Config File Load Failure | Config File | Config File Load | Copy a correct |
| 2 | | Load Failure | Failure | configuration file from a |
| | | | | normal operating robot. |
| | | | | |
| 341 | Config File lose root | Config File | Config File loses | Copy a correct |
| 3 | element | loses the root | the root element | configuration file from a |
| | | element | | normal operating robot. |
| 341 | Unknown Robot Type | Unknown | Unknown Robot | Copy a correct |
| 4 | | Robot Type | Туре | configuration file from a |
| | | | | normal operating robot. |
| 341 | XML file data irregular | Invalid data in | Invalid data in | Copy a correct |
| 5 | | Xml file | Xml file | configuration file from a |
| | | | | normal operating robot. |
| 341 | ArcWelding file Load | Welding file | Welding file | Copy a correct welding |
| 6 | Failure | definition error | definition error | file from a normal |
| | | | | operating robot. |





| 0.11 | MALE FILE | 1 | 1 | 0 |
|------|---------------------------|------------------|-------------------|-------------------------|
| 341 | Welding File data | Invalid data in | Invalid data in a | Copy a correct welding |
| 7 | irregular | a welding file | welding file | file from a normal |
| | | | | operating robot. |
| 341 | Welding File lose root | Welding File | Welding File | Copy a correct welding |
| 8 | element | loses the root | loses the root | file from a normal |
| | | element. | element. | operating robot. |
| 341 | Touch File load failed | Searching file | Searching file | Copy a correct |
| 9 | | load failure | load failure | searching file from a |
| | | | | normal operating robot. |
| 342 | Touch File data irregular | Invalid data in | Invalid data in a | Copy a correct |
| 0 | | a searching | searching file | searching file from a |
| | | file | | normal operating robot. |
| 342 | Touch File lose root | Searching file | Searching file | Copy a correct |
| 1 | element | loses the root | loses the root | searching file from a |
| | | element | element | normal operating robot. |
| 342 | CD file data num err | Data number | Data number | Copy a correct |
| 2 | | error in a | error in a | searching file from a |
| | | searching file | searching file | normal operating robot. |
| 342 | ID description file err | Error | Error description | Copy a correct error |
| 3 | | description file | file goes wrong | description file from a |
| | | goes wrong | | normal operating robot |
| 342 | MultiLayer data file lost | Multilayer and | Forget to copy or | Copy a correct error |
| 4 | | multichannel | import it | description file from a |
| | | data file is | | normal operating robot |
| | | missing | | |
| 342 | MultiLayer file lose root | Multilayer and | system files | Submit a BUG |
| 5 | | multichannel | process | |
| | | data file is | abnormally. | |
| | | damaged | | |
| | <u> </u> | 1 | l . | l |





| 342 MultiLayer file lost Lack of the multilayer and multichannel variables MultiLayer pathMemo variables 342 MultiLayer pathMemo variables Setpc operation operation is restricted for use 342 Cannot find the Pallet Var variables Cannot find the Pallet Var variables Cannot find the Pallet Var variables 8 | | | T | | |
|--|-----|----------------------------|-----------------|--------------------|-------------------------|
| multichannel variables 342 MultiLayer pathMemo Setpc operation cannot be used at the moment. 342 Cannot find the Pallet Var use 342 Cannot find the Pallet Var Cannot find the Pallet Var deleted by maloperation 342 Cannot find the Pallet ref the Pallet var deleted by maloperation 343 Pallet data initial error Abnormal pallet position 344 Pallet act num The number of running pallet variable will be greater or less than the set value 345 Pallet dynamic param Singular Dyn Param in the deleted by maram in the deleted by maloperation 346 Recreate it deleted by maloperation 347 Pallet data initial error Abnormal pallet variables are deleted by maloperation 348 Pallet data initial error Abnormal pallet variable will the actual number. 349 Pallet dynamic param Singular Dyn param in the deleted by Recreate it deleted by Pallet data has problems, which may be the singular position. 340 Pallet dynamic param Singular Dyn param in the deleted by Recreate it | 342 | MultiLayer file lost | Lack of the | The variables are | Recreate it |
| Variables Vari | 6 | variable | multilayer and | deleted by | |
| MultiLayer pathMemo Setpc operation is restricted for use 342 Cannot find the Pallet Var the Pallet Var deleted by maloperation 342 Cannot find the Pallet ref the Pallet var deleted by maloperation 343 Pallet act num error, greater or less 343 Pallet dynamic param 344 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 341 Pallet dynamic param 342 Cannot find the Pallet var deleted by maloperation 343 Pallet dynamic param 344 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 341 Pallet dynamic param 342 Pallet dynamic param 343 Pallet dynamic param 344 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 341 Pallet dynamic param 342 Pallet dynamic param 343 Pallet dynamic param 344 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 341 Pallet dynamic param 342 Pallet dynamic param 343 Pallet dynamic param 344 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 341 Pallet dynamic param 342 Pallet dynamic param 343 Pallet dynamic param 344 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 341 Pallet dynamic param 342 Pallet dynamic param 343 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 | | | multichannel | maloperation | |
| SetPC forbid operation is restricted for use 342 Cannot find the Pallet Var the Pallet Var deleted by maloperation 342 Cannot find the Pallet ref the Pallet Var deleted by maloperation 343 Pallet act num error, greater or less Pallet wariable will be greater or less than the set value 343 Pallet dynamic param 2 Singular Dyn error 344 Pallet dynamic param 2 Singular Dyn error use 345 Cannot find the Pallet Var deleted by maloperation 346 Cannot find the Pallet ref the Pallet Var deleted by maloperation 347 Cannot find the Pallet ref the Pallet Var deleted by maloperation 348 Pallet data initial error Abnormal pallet data has problems, which may be the singular position. 349 Pallet act num the actual number. 340 Pallet dynamic param Singular Dyn param in the deleted by 340 Pallet dynamic param en the deleted by 341 Pallet dynamic param en the deleted by 342 Pallet dynamic param en the deleted by 343 Pallet dynamic param en the deleted by | | | variables | | |
| restricted for use The moment. The variables are deleted by maloperation The pallet data has pallet position The pallet data has pallet position The number of running pallet variable will be greater or less than the set value The number. The number. The number. The number of running pallet isn't consistent with the actual number. The variables are deleted by reference and the pallet isn't consistent with the actual number. The variables are deleted by | 342 | MultiLayer pathMemo | Setpc | Setpc operation | Setpc is started from |
| Section Sect | 7 | SetPC forbid | operation is | cannot be used at | somewhere else or the |
| 342 Cannot find the Pallet Var deleted by maloperation 342 Cannot find the Pallet ref the Pallet var deleted by maloperation 343 Pallet act num error, greater or less running pallet variable will be greater or less than the set value 343 Pallet dynamic param 2 Singular poyr of the variables are deleted by maloperation The variables are deleted by maloperation The variables are deleted by maloperation Pallet data has problems, which may be the singular position. The number of running pallet variable will consistent with the actual number. Set value The variables are decreate it deleted by maloperation The variables are number of pallet isn't consistent with the actual number. Set value The variables are Recreate it deleted by Recreate it Recreate it deleted by Recreate it Recreate | | | restricted for | the moment. | first line. |
| the Pallet Var deleted by maloperation 342 Cannot find the Pallet ref the Pallet deleted by reference coordinate system 343 Pallet data initial error Abnormal pallet position pallet position. 344 Pallet act num The number of error, greater or less running pallet variable will be greater or less than the set value 343 Pallet dynamic param Singular Dyn param in the deleted by maloperation 344 Recreate it deleted by maloperation 345 Recreate it deleted by maloperation 346 Recreate it deleted by maloperation 347 Pallet data has problems, which may be the singular position. 348 Pallet dynamic param Singular Dyn The variables are deleted by Recreate it deleted by | | | use | | |
| maloperation The variables are deleted by reference coordinate system 343 Pallet data initial error Abnormal pallet position The number of running pallet isn't consistent with be greater or less than the set value 343 Pallet dynamic param Singular Dyn error Pallet dynamic param in the deleted by maloperation The variables are deleted by maloperation Recreate it Recreate it The variables are deleted by maloperation The variables are deleted by Redemonstrate the pallet data Redemonstrate the pallet data Redemonstrate the pallet data Pallet data Redemonstrate the pallet data Redemonstrate the pallet data Pallet data Redemonstrate the pallet data Redemonstrate the pallet data Pallet data The number of param in the deleted by | 342 | Cannot find the Pallet Var | Cannot find | The variables are | Recreate it |
| 342 Cannot find the Pallet ref the Pallet the Pallet the Pallet reference coordinate system 343 Pallet data initial error Abnormal pallet position The number of running pallet variable will be greater or less than the set value 343 Pallet dynamic param 2 error The variables are deleted by maloperation Recreate it The variables are deleted by maloperation Pallet data has problems, which may be the singular position. Check the program logic or reload. Check the program logic or reload. The actual number. Set value The variables are deleted by maloperation Recreate it | 8 | | the Pallet Var | deleted by | |
| the Pallet reference coordinate system 343 Pallet data initial error Abnormal pallet position Poblems, which may be the singular position. 343 Pallet act num The number of running pallet variable will be greater or less than the set value 343 Pallet dynamic param Singular Dyn param in the deleted by the Pallet deted by maloperation Redemonstrate the pallet data Redemonstrate the pallet data Redemonstrate the pallet data Pallet data Redemonstrate the pallet data Pallet data Abnormal problems, which may be the singular position. The number of pallet isn't consistent with the actual number. | | | | maloperation | |
| reference coordinate system 343 Pallet data initial error Abnormal pallet position Pallet data has pallet data pallet data 444 Pallet act num Pallet position Pallet isn't p | 342 | Cannot find the Pallet ref | Cannot find | The variables are | Recreate it |
| coordinate system 343 Pallet data initial error Abnormal pallet position Pallet data has problems, which may be the singular position. The number of running pallet variable will be greater or less than the set value 343 Pallet dynamic param 2 error Check the program logic or reload. | 9 | | the Pallet | deleted by | |
| system 343 Pallet data initial error Abnormal pallet position pallet position pallet data has pallet data pallet data pallet data pallet data pallet data pallet data Pallet data pallet data Redemonstrate the pallet data Pallet data Pallet data The number of pallet isn't pallet isn't consistent with be greater or less than the set value 343 Pallet dynamic param Pallet data problems, which pallet data Check the program logic or reload. Pallet data The number of pallet isn't consistent with the actual number. Set value The variables are deleted by Recreate it | | | reference | maloperation | |
| 343 Pallet data initial error Abnormal pallet position Pallet data has problems, which may be the singular position. The number of running pallet variable will be greater or less than the set value 343 Pallet data initial error Pallet data has problems, which may be the singular position. Check the program logic or reload. Or reload. The actual number. Set value Redemonstrate the pallet data | | | coordinate | | |
| pallet position problems, which may be the singular position. 343 Pallet act num The number of running pallet pallet isn't consistent with be greater or less than the set value 343 Pallet dynamic param Singular Dyn param in the deleted by pallet data The number, which may be the singular position. The number of pallet isn't consistent with the actual number. Set value Pallet data The number of param pallet isn't consistent with the actual number. The variables are deleted by | | | system | | |
| may be the singular position. 343 Pallet act num error,greater or less The number of pallet isn't or reload. variable will consistent with be greater or less than the number. set value 343 Pallet dynamic param 2 error may be the singular position. Check the program logic or reload. running pallet pallet isn't or reload. running pallet pallet isn't or reload. Recreate it deleted by | 343 | Pallet data initial error | Abnormal | Pallet data has | Redemonstrate the |
| singular position. 343 Pallet act num 1 error,greater or less 2 running pallet 2 error 343 Pallet dynamic param 2 error 344 Pallet dynamic param 2 error 345 Pallet act num 346 The number of 347 The number of 348 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 341 Pallet dynamic param 343 Pallet dynamic param 343 Pallet dynamic param 344 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 341 Pallet dynamic param 342 Pallet dynamic param 343 Pallet dynamic param 343 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 341 Pallet dynamic param 342 Pallet dynamic param 343 Pallet dynamic param 345 Pallet dynamic param 346 Pallet dynamic param 347 Pallet dynamic param 348 Pallet dynamic param 349 Pallet dynamic param 349 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param 340 Pallet dynamic param | 0 | | pallet position | problems, which | pallet data |
| 343 Pallet act num The number of running pallet variable will be greater or less than the set value 343 Pallet dynamic param 2 error The number of pallet isn't or reload. The variable sare Recreate it deleted by | | | | may be the | |
| 1 error,greater or less running pallet variable will consistent with be greater or less than the set value 343 Pallet dynamic param Singular Dyn The variables are Recreate it param in the deleted by | | | | singular position. | |
| variable will be greater or less than the number. 343 Pallet dynamic param Singular Dyn The variables are param in the deleted by | 343 | Pallet act num | The number of | The number of | Check the program logic |
| be greater or the actual less than the number. 343 Pallet dynamic param Singular Dyn The variables are Recreate it param in the deleted by | 1 | error,greater or less | running pallet | pallet isn't | or reload. |
| less than the set value 343 Pallet dynamic param Singular Dyn The variables are Recreate it param in the deleted by | | | variable will | consistent with | |
| set value 343 Pallet dynamic param Singular Dyn The variables are Recreate it 2 error param in the deleted by | | | be greater or | the actual | |
| 343 Pallet dynamic param Singular Dyn The variables are Recreate it 2 error param in the deleted by | | | less than the | number. | |
| 2 error param in the deleted by | | | set value | | |
| | 343 | Pallet dynamic param | Singular Dyn | The variables are | Recreate it |
| pallet maloperation | 2 | error | param in the | deleted by | |
| | | | pallet | maloperation | |





| | | statement | | |
|----------|--|--|---|---|
| 343 | Pallet overlap param error | Singular Ovl parameter in the pallet statement | The variables are deleted by maloperation | Recreate it |
| 343 | Pallet unknown command error | Unknown pallet statement type | System files process abnormally. | Submit a BUG |
| 343 5 | Cannot find the Pallet finish bool var | Singular Bool param in the pallet statement | The variables are deleted by maloperation | Recreate it |
| 343 | Cannot find the Pallet Reset var | Pallet variable is missing | The variables are deleted by maloperation | Recreate it |
| 343 | Aux num greater than you have purchased | The number of equipped AuxJoints is greater than that of what you have purchased | Contact with the sailor | Contact with the sailor |
| 343 8 | SP variable used after MultiLayer Initial | SP variable must be used | Firstly initialize, and then use SP | SP variable must be used after the multilayer |



| | | after the | point. | and multichannel |
|-----|-------------------------|----------------|---------------------|---------------------------|
| | | multilayer and | | initialization. See the |
| | | multichannel | | instruction. |
| | | initialization | | |
| 343 | Pallet variable number | The number of | At most ten pallet | Delete the unnecessary |
| 9 | out limit | pallet | variables are built | pallet variable |
| | | variables is | into a program. | |
| | | beyond the | | |
| | | limits. | | |
| 344 | Cannot find the | Cannot find | The variables are | Recreate it |
| 0 | MultiLayer data | the multilayer | deleted by | |
| | | and | maloperation | |
| | | multichannel | | |
| | | data | | |
| 344 | Pathmemo cannot | Pathmemo | Setpc operation | Setpc is started from |
| 1 | towards the backward | can only | cannot be used at | somewhere else or the |
| | setpc | record the | the moment. | first line. |
| | | previous | | |
| | | statements. | | |
| 344 | Pathmemo not initial | The statement | Firstly initialize, | The statement must be |
| 2 | | must be used | and then use SP | used after the multilayer |
| | | after the | point. | and multichannel |
| | | multilayer and | | initialization. See the |
| | | multichannel | | instruction. |
| | | initialization | | |
| 344 | Pathmemo param not find | Lack of | The variables are | Recreate it |
| 3 | | Pathmemo | deleted by | |
| | | parameter | maloperation | |



| 344 | PointCorrect not | Parameters in | Usage error | Reconfirm the using |
|-----|------------------------|-----------------------------|-------------------|---------------------|
| 4 | accordance with | PointCorrect | | method. See the |
| | MulitiLayer | statement | | instruction. |
| | | aren't | | |
| | | consistent | | |
| | | with the | | |
| | | current | | |
| | | multilayer and | | |
| | | multichannel | | |
| | | variables. | | |
| 344 | PointCorrect 2th param | Lack of the 2 nd | The variables are | Recreate it |
| 5 | error | parameter in | deleted by | |
| | | PointCorrect | maloperation | |
| | | statement | | |
| 344 | PointCorrect 3th param | Lack of the 3 rd | The variables are | Recreate it |
| 6 | error | parameter in | deleted by | |
| | | PointCorrect | maloperation | |
| | | statement | | |
| 344 | PointCorrect 4th param | Lack of the 4 th | The variables are | Recreate it |
| 7 | not find | parameter in | deleted by | |
| | | PointCorrect | maloperation | |
| | | statement | | |
| 344 | LayerLoop not | Parameters in | Usage error | Reconfirm the using |
| 8 | accordance with | LayerLoop | | method. See the |
| | MulitiLayer | statement | | instruction. |
| | | aren't | | |
| | | consistent | | |
| | | with the | | |
| | | current | | |





| 9 outi | ayerLoop cycle time atrange TP 1th param not find TP 1th param type error | multilayer and multichannel variables. The number of loops in LayerLoop is beyond the set. Cannot find the 1st parameter in the statement The 1st parameter type error in | Usage error The variables are deleted by maloperation Usage error | Reconfirm the using method. See the instruction. Recreate it Reconfirm the using method. See the instruction. |
|------------------------------------|---|--|---|---|
| 9 outs 345 PTF 1 345 PTF 2 345 PTF | Itrange | variables. The number of loops in LayerLoop is beyond the set. Cannot find the 1st parameter in the statement The 1st parameter | The variables are deleted by maloperation | method. See the instruction. Recreate it Reconfirm the using method. See the |
| 9 outs 345 PTF 1 345 PTF 2 345 PTF | Itrange | The number of loops in LayerLoop is beyond the set. Cannot find the 1st parameter in the statement The 1st parameter | The variables are deleted by maloperation | method. See the instruction. Recreate it Reconfirm the using method. See the |
| 9 outs 345 PTF 1 345 PTF 2 345 PTF | Itrange | loops in LayerLoop is beyond the set. Cannot find the 1 st parameter in the statement The 1 st parameter | The variables are deleted by maloperation | method. See the instruction. Recreate it Reconfirm the using method. See the |
| 345 PTF 1 345 PTF 2 345 PTF | ΓΡ 1th param not find | LayerLoop is beyond the set. Cannot find the 1st parameter in the statement The 1st parameter | deleted by maloperation | Recreate it Reconfirm the using method. See the |
| 345 PTF 2 345 PTF | | beyond the set. Cannot find the 1 st parameter in the statement The 1 st parameter | deleted by maloperation | Recreate it Reconfirm the using method. See the |
| 345 PTF 2 345 PTF | | set. Cannot find the 1 st parameter in the statement The 1 st parameter | deleted by maloperation | Reconfirm the using method. See the |
| 345 PTF 2 345 PTF | | Cannot find the 1 st parameter in the statement The 1 st parameter | deleted by maloperation | Reconfirm the using method. See the |
| 345 PTF 2 345 PTF | | the 1 st parameter in the statement The 1 st parameter | deleted by maloperation | Reconfirm the using method. See the |
| 345 PTF 2 345 PTF | ΓΡ 1th param type error | parameter in the statement The 1 st parameter | maloperation | method. See the |
| 1 345 PTF 345 PTF | ΓΡ 1th param type error | the statement The 1 st parameter | | method. See the |
| 1 345 PTF 345 PTF | ΓΡ 1th param type error | The 1 st parameter | Usage error | method. See the |
| 1 345 PTF 345 PTF | ΓP 1th param type error | parameter | Usage error | method. See the |
| 345 PTF 2 345 PTF | | | | |
| 2 345 PTF | | type error in | | instruction. |
| 2 345 PTF | | | | |
| 2 345 PTF | | the statement | | |
| 345 PTF | ΓP 2th param error | Cannot find | The variables are | Recreate it |
| | | the 2 nd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 3 | ΓP 3th param error | Cannot find | The variables are | Recreate it |
| | | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 345 Lin | | Cannot find | The variables are | Recreate it |
| 4 | n 1th param not find | the 1 st | deleted by | |
| | n 1th param not find | parameter in | maloperation | |
| | n 1th param not find | parameter in | • | |
| 345 Lin | n 1th param not find | the statement | | |





| 5 | | parameter | | method. See the |
|-----|---------------------------|---------------------|-------------------|---------------------|
| | | type error in | | instruction. |
| | | the statement | | |
| 345 | Lin 2th param error | Cannot find | The variables are | Recreate it |
| 6 | | the 2 nd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 345 | Lin 3th param error | Cannot find | The variables are | Recreate it |
| 7 | | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 345 | Lin 4th param error | Cannot find | The variables are | Recreate it |
| 8 | | the 4 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 345 | Circ 1th param not find | Cannot find | The variables are | Recreate it |
| 9 | | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 346 | Circ 1th param type error | The 1 st | Usage error | Reconfirm the using |
| 0 | | parameter | | method. See the |
| | | type error in | | instruction. |
| | | the statement | | |
| 346 | Circ 2th param not find | Cannot find | The variables are | Recreate it |
| 1 | | the 2 nd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 346 | Circ 2th param type error | The 2 nd | Usage error | Reconfirm the using |
| 2 | | parameter | | method. See the |





| | | type error in | | instruction. |
|-----|--------------------------|---------------------|-------------------|---------------------|
| | | the statement | | |
| 346 | Circ 3th param error | Cannot find | The variables are | Recreate it |
| 3 | | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 346 | Circ 4th param error | Cannot find | The variables are | Recreate it |
| 4 | | the 4 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 346 | Circ 5th param error | Cannot find | The variables are | Recreate it |
| 5 | | the 5 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 346 | CircAngle 1th param not | Cannot find | The variables are | Recreate it |
| 6 | find | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 346 | CircAngle 1th param type | The 1 st | Usage error | Reconfirm the using |
| 7 | error | parameter | | method. See the |
| | | type error in | | instruction. |
| | | the statement | | |
| 346 | CircAngle 2th param not | The 2 nd | The variables are | Recreate it |
| 8 | find | parameter | deleted by | |
| | | type error in | maloperation | |
| | | the statement | | |
| 346 | CircAngle 2th param type | The 2 nd | Usage error | Reconfirm the using |
| 9 | error | parameter | | method. See the |
| | | type error in | | instruction. |





| | | the statement | | |
|-----|---------------------------|---------------------|-------------------|---------------------|
| 347 | CircAngle 3th param error | Cannot find | The variables are | Recreate it |
| 0 | | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 347 | CircAngle 4th param error | Cannot find | The variables are | Recreate it |
| 1 | | the 4 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 347 | CircAngle 5th param error | Cannot find | The variables are | Recreate it |
| 2 | | the 5 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 347 | CircAngle 6th param error | Cannot find | The variables are | Recreate it |
| 3 | | the 6 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 347 | Search_L 1th param not | Cannot find | The variables are | Recreate it |
| 4 | find | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 347 | Search_L 1th param type | The 1 st | Usage error | Reconfirm the using |
| 5 | error,not support | parameter | | method. See the |
| | | type error in | | instruction. |
| | | the statement | | |
| 347 | Search_L 2th param not | Cannot find | The variables are | Recreate it |
| 6 | find | the 2 nd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |



| | | | | T |
|-----|-------------------------|---------------------|-------------------|---------------------|
| 347 | Search_L 3th param not | Cannot find | The variables are | Recreate it |
| 7 | find | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 347 | Search_T 1th param not | Cannot find | The variables are | Recreate it |
| 8 | find | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 347 | Search_T 1th param type | The 1 st | Usage error | Reconfirm the using |
| 9 | error,not support | parameter | | method. See the |
| | | type error in | | instruction. |
| | | the statement | | |
| 348 | Search_T 2th param not | Cannot find | The variables are | Recreate it |
| 0 | find | the 2 nd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 348 | Search_T 3th param not | Cannot find | The variables are | Recreate it |
| 1 | find | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 348 | CORR_1D param not find | Cannot find | The variables are | Recreate it |
| 2 | | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 348 | CORR_2D 1th param not | Cannot find | The variables are | Recreate it |
| 3 | find | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 348 | CORR_2D 2th param not | Cannot find | The variables are | Recreate it |





| 4 | find | the 2 nd | deleted by | |
|-----|-----------------------|---------------------|-------------------|-------------|
| | | parameter in | maloperation | |
| | | the statement | | |
| 348 | CORR_3D 1th param not | Cannot find | The variables are | Recreate it |
| 5 | find | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 348 | CORR_3D 2th param not | Cannot find | The variables are | Recreate it |
| 6 | find | the 2 nd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 348 | CORR_3D 3th param not | Cannot find | The variables are | Recreate it |
| 7 | find | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 348 | CORR_6D 1th param not | Cannot find | The variables are | Recreate it |
| 8 | find | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 348 | CORR_6D 2th param not | Cannot find | The variables are | Recreate it |
| 9 | find | the 2 nd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 349 | CORR_6D 3th param not | Cannot find | The variables are | Recreate it |
| 0 | find | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 349 | CORR_6D 4th param not | Cannot find | The variables are | Recreate it |
| 1 | find | the 4 th | deleted by | |





| | | parameter in | maloperation | |
|-----|-----------------------|---------------------|-------------------|--------------------------|
| | | the statement | | |
| 349 | CORR_6D 5th param not | Cannot find | The variables are | Recreate it |
| 2 | find | the 5 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 349 | CORR_6D 6th param not | Cannot find | The variables are | Recreate it |
| 3 | find | the 6 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 349 | ARCON param not find | Lack of | The variables are | Recreate it |
| 4 | | parameters in | deleted by | |
| | | the statement | maloperation | |
| 349 | ARCOFF param not find | Lack of | The variables are | Recreate it |
| 5 | | parameters in | deleted by | |
| | | the statement | maloperation | |
| 349 | ARCSET param not find | Lack of | The variables are | Recreate it |
| 6 | | parameters in | deleted by | |
| | | the statement | maloperation | |
| 350 | PLC Command data is | PLCInterface | Data | Check whether the |
| 0 | empty | command | transmission is | revision information is |
| | | data is empty | chaos. | consistent or not. |
| 350 | Authority is busy | Authority is | When one | Determine whether other |
| 1 | | occupied. | interface is | operation interfaces |
| | | | getting the | release the authority or |
| | | | authority, other | not. If not, the granted |
| | | | operation | authority can be |
| | | | interfaces don't | released through the |
| | | | release it. | demonstrator or PLC |



| | | | | programming. |
|-----|---------------------------|-----------------|--------------------|----------------------------|
| | | | | |
| 351 | Load program when | Reload the | Reload the | If a new program is |
| 0 | loading state | program | program | loaded, firstly unload the |
| | | | | loaded program firstly. |
| 351 | program is illegal format | Invalid | | If the program statement |
| 1 | | program | | format goes wrong, |
| | | format | | revise the statement. |
| | | | | See the statement |
| | | | | format in the instruction. |
| 351 | Adjacency list | The inner | Inner | Reload and submit a |
| 2 | construction failure | construction of | construction of a | bug |
| | | the program is | program is failed. | |
| | | failed | | |
| | | | | |
| 351 | Program file wrong | Program file | | For lack of a program |
| 3 | | name goes | | file, create a new file |
| | | wrong | | with the same name. |
| | | | | Note: the suffix is srp |
| 352 | Start or load command is | Start or load | | Submit a BUG |
| 0 | failure | command is | | |
| | | failed | | |
| 352 | Software not register | Unregistered | The software isn't | It needs to get the |
| 1 | | software | registered | correct registration code |
| | | | correctly | and register. |
| 352 | Invalid register key | Invalid | The registration | It needs to get the |
| 2 | | registration | code is wrong. | correct registration code |
| | | code | | and register. |





| Copy a correct information file Lack of the user Copy a correct information file Information file | al operating |
|---|--------------|
| Ioad failure robot | e using |
| 370 LinISR Pose type not When the types of the consistent method. See input and output positions aren't consistent in | _ |
| types of the input and instruction. output positions aren't consistent method. See | _ |
| input and instruction. output positions aren't consistent in | the |
| output positions aren't consistent in | |
| positions aren't consistent in | |
| aren't consistent in | |
| consistent in | |
| | |
| the statement, | |
| | |
| it reports an | |
| error. | |
| 370 LinISR Pose type forbid The statement the type Reconfirm the | e using |
| 1 doesn't allow restriction error method. See | the |
| this type of instruction. | |
| variable | |
| 370 FeedBackPose type | e using |
| 2 forbid position type restriction error method. See | the |
| isn't allowed instruction. | |
| 370 LinISR 1th param not find Cannot find The variables are Recreate it | |
| 3 the 1 st deleted by | |
| parameter in maloperation | |
| the statement | |
| 370 LinISR 1th param type The 1 st Usage error Reconfirm the | e using |
| 4 error,not support parameter method. See | the |
| type error in instruction. | |
| the statement | |
| 370 LinISR 2th param not find Cannot find The variables are Recreate it | |





| 5 | | the 2 nd | deleted by | |
|-----|---------------------------|---------------------|-------------------|---------------------|
| | | parameter in | maloperation | |
| | | the statement | | |
| 370 | LinISR 3th param not find | Cannot find | The variables are | Recreate it |
| 6 | | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 370 | LinISR 4th param not find | Cannot find | The variables are | Recreate it |
| 7 | | the 4 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 370 | LinISR 5th param not find | Cannot find | The variables are | Recreate it |
| 8 | | the 5 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 370 | LinISR 6th param not find | Cannot find | The variables are | Recreate it |
| 9 | | the 6 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 371 | WLin 1th param not find | Cannot find | The variables are | Recreate it |
| 1 | | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 371 | WLin 1th param type | The 1 st | Usage error | Reconfirm the using |
| 2 | error,not support | parameter | | method. See the |
| | | type error in | | instruction. |
| | | the statement | | |
| 371 | WLin 2th param not find | Cannot find | The variables are | Recreate it |
| 3 | | the 2 nd | deleted by | |





| | | parameter in | maloperation | |
|-----|--------------------------|---------------------|-------------------|---------------------|
| | | the statement | | |
| 371 | WLin 3th param not find | Cannot find | The variables are | Recreate it |
| 4 | | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 371 | WLin 4th param not find | Cannot find | The variables are | Recreate it |
| 5 | | the 4 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 371 | WLin 5th param not find | Cannot find | The variables are | Recreate it |
| 6 | | the 5 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 371 | WLin 6th param not find | Cannot find | The variables are | Recreate it |
| 7 | | the 6 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 371 | WCirc 1th param not find | Cannot find | The variables are | Recreate it |
| 8 | | the 1 st | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 371 | WCirc 1th param type | The 1 st | Usage error | Reconfirm the using |
| 9 | error,not support | parameter | | method. See the |
| | | type error in | | instruction. |
| | | the statement | | |
| 372 | WCirc 2th param not find | Cannot find | The variables are | Recreate it |
| 0 | | the 2 nd | deleted by | |
| | | parameter in | maloperation | |





| | | the statement | | |
|-----|--------------------------|---------------------|-------------------|---------------------|
| 372 | WCirc 2th param type | The 2 nd | Usage error | Reconfirm the using |
| 1 | error,not support | parameter | | method. See the |
| | | type error in | | instruction. |
| | | the statement | | |
| 372 | WCirc 3th param not find | Cannot find | The variables are | Recreate it |
| 2 | | the 3 rd | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 372 | WCirc 4th param not find | Cannot find | The variables are | Recreate it |
| 3 | | the 4 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 372 | WCirc 5th param not find | Cannot find | The variables are | Recreate it |
| 4 | | the 5 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 372 | WCirc 6th param not find | Cannot find | The variables are | Recreate it |
| 5 | | the 6 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 372 | WCirc 7th param not find | Cannot find | The variables are | Recreate it |
| 6 | | the 7 th | deleted by | |
| | | parameter in | maloperation | |
| | | the statement | | |
| 372 | ARCJOB param not find | Parameters | The variables are | Recreate it |
| 7 | | cannot be | deleted by | |
| | | found in the | maloperation | |
| | | statement | | |



| 372 | ARCMODE param not | Parameters | The variables are | Recreate it |
|-----|----------------------------|------------------|---------------------|-------------------------|
| 8 | find | cannot be | deleted by | |
| | | found in the | maloperation | |
| | | statement | | |
| 372 | This type var not support | The type of | Usage error | Reconfirm the using |
| 9 | save operation | parameters | | method. See the |
| | | cannot be | | instruction. |
| | | saved in the | | |
| | | file | | |
| 373 | Cannot call global or | Cannot call | Usage error | Reconfirm the using |
| 0 | project var | global or | | method. See the |
| | | project var in | | instruction. |
| | | the statement | | |
| 373 | JiaoDi File load failed | Car platform | The file is missing | Copy a correct error |
| 1 | | data file load | or damaged | description file from a |
| | | failure | | normal operating robot |
| 373 | JiaoDi File lose root | Car platform | The data are | Copy a correct error |
| 2 | element | data file is | invalidly missing | description file from a |
| | | damaged | or damaged | normal operating robot |
| 373 | JiaoDi File data irregular | Data in car | The data are | Copy a correct error |
| 3 | | platform data | invalidly missing | description file from a |
| | | file are invalid | or damaged | normal operating robot |
| 373 | HMI request file not find | The file | Lack of the file | Create a new file with |
| 4 | | needed by the | | the same name |
| | | demonstrator | | |
| | | doesn't exist. | | |
| 373 | HMI send file not exist in | The file | Lack of the file | Create a new file with |
| 5 | NonReal | needed by the | | the same name |
| | | demonstrator | | |





| | | doesn't exist. | | |
|-----|---------------------------|-----------------|--------------------|---------------------------|
| 380 | Weave Data Format Err | Invalid format | The format isn't | Add two new data in the |
| 0 | | of swing arc | consistent with | end of variables, both of |
| | | variables | the original one | which is 0. |
| | | | after the software | |
| | | | upgrading. | |
| 380 | Bool Data Format Err | Invalid format | Invalid missing or | Delete the original |
| 1 | | of bool | damaging of data | variables and create a |
| | | variables | | new variable with the |
| | | | | same name. |
| 380 | Only Input UINT Type Var | Only Input | Usage error | Reconfirm the using |
| 2 | | UINT Type | | method. See the |
| | | Var | | instruction. |
| 380 | variables not within the | Variable is not | Usage error | Reconfirm the using |
| 3 | scope | within the | | method. See the |
| | | scope. | | instruction. |
| 400 | Program has not loaded | Program has | When starting the | The robot shall load the |
| 0 | | not loaded | program, there is | program before running |
| | | | no program | it. |
| | | | loading. | |
| 400 | Robot has not enabled | Robot has not | When starting the | The robot shall have |
| 1 | | enabled | program, the | enabled before running |
| | | | robot has not | it. |
| | | | enabled | |
| 400 | Do not jog when robot run | Cannot jog | Cannot jog when | Switch to the manual |
| 2 | in auto_mode | when robot | robot runs in | mode to jog |
| | | runs in | auto_mode | |
| | | auto_mode | | |





| 400 | Do not Load a new | Cannot load a | Cannot load a | It shall not load a new |
|-----|--------------------------|---------------|------------------|-----------------------------|
| 3 | program when robot is | new program | new program | program when robot is |
| | running | when robot is | when robot is | running |
| | | running | running | |
| 400 | Do not jog when robot is | Cannot jog | Cannot jog when | It shall not jog when |
| 4 | moving | when robot is | robot is running | robot is running |
| | | running | | |
| 400 | Do not kill the program | Cannot close | Not follow the | It shall firstly suspend or |
| 5 | when robot is moving | the program | requests to | stop and then close the |
| | | when robot is | operate | program, |
| | | running | | |
| 400 | Do not Load a new | Cannot load a | Not follow the | It shall firstly close the |
| 6 | program when robot is | new program | requests to | program and then load |
| | moving | when robot is | operate | the program after |
| | | running | | stopping the robot. |
| 400 | Do not operate program | Cannot edit | Not follow the | It shall edit program after |
| 7 | when robot is moving | program when | requests to | stopping the robot. |
| | | robot is | operate | |
| | | running | | |
| 400 | Do not change run mode | Cannot | Not follow the | It shall change run mode |
| 9 | when robot is moving | change run | requests to | after stopping the robot. |
| | | mode when | operate | |
| | | robot is | | |
| | | running | | |
| 401 | Do not active ToolAlign | Cannot active | Not follow the | It shall active ToolAlign |
| 0 | when robot is moving | ToolAlign | requests to | after stopping the robot. |
| | | when robot is | operate | |
| | | running | | |
| 401 | Do not press Start when | Cannot press | Not follow the | It shall press Start after |
| | | | | |





| 1 | doing ToolAlign | Start when | requests to | stopping the robot. |
|-----|----------------------------|----------------|------------------|-------------------------|
| | | robot is doing | operate | |
| | | ToolAlign. | | |
| 401 | Do not active ToolAlign in | Cannot active | Not follow the | Switch to the manual |
| 2 | AutoMode | ToolAlign in | requests to | mode |
| | | AutoMode | operate | |
| 401 | Do not active | Cannot active | Not follow the | It shall make the robot |
| 3 | JogToPosition when | JogToPosition | requests to | stop. |
| | robot is moving | when robot is | operate | |
| | | running | | |
| 401 | Do not press Start when | Cannot press | Not follow the | Two operations cannot |
| 4 | doing JogToPosition | Start when | requests to | be carried out |
| | | robot is doing | operate | simultaneously. |
| | | JogToPosition | | |
| | | | | |
| 401 | Do not active | Cannot active | Not follow the | Switch to the manual |
| 5 | JogToPosition in | JogToPosition | requests to | mode |
| | AutoMode | in AutoMode | operate | |
| 401 | The drive hardware | There is no | | Open the servo |
| 6 | enable is false | enable in the | | hardware enable. |
| | | servo | | |
| | | hardware. | | |
| 401 | Error Not Clear | Error isn't | Not clear the | Open the enable after |
| 7 | | clear. | error before | clearing the error |
| | | | opening the | |
| | | | enable | |
| 401 | Not Disable When | Close the | Close the enable | Closing the enable |
| 8 | ProgramRuning | enable when | when robot is | temporarily |
| | | robot is | running. | |



| | | running. | | |
|-----|--|---|---|-------------------------------------|
| 450 | Relative overlap parameter is greater than | Relative overlap | - | Submit a BUG |
| | one | parameter is greater than one | | |
| 450 | Relative overlap parameter is less than zero | Relative overlap parameter is | - | Submit a BUG |
| 450 | OvlAbs parameter LinAx | Absolute | - | Submit a BUG |
| 2 | is less than zero | overlap linear velocity is less than zero | | |
| 450 | OvlAbs parameter JointDeg is less than zero | Absolute overlap angular velocity is less than zero | - | Submit a BUG |
| 460 | The orientation is not Norm | The postures aren't normalized | - | Fine tune the target point of robot |